



**HEIDENHAIN**



**User's Manual**


**ND 231 B**

**Measured Value Displays**







6/2000


**Actual value and input display**  
(9 decades and algebraic sign)

**Numeric keypad  
with decimal point**



**Status display with  
backlit indicators**

Key	Function
	<ul style="list-style-type: none"> <li>Datum setting</li> <li>Confirming the entry value</li> <li>Setting display to value from P79 (P80!)</li> <li>Exiting the parameter list</li> </ul>
	<ul style="list-style-type: none"> <li>Datum selection</li> <li>Paging backward in the parameter list</li> </ul>
	<ul style="list-style-type: none"> <li>Outputting the meas. value with "PRINT"</li> <li>Selecting parameters after switch-on</li> <li>Paging forward in the parameter list</li> </ul>
	<ul style="list-style-type: none"> <li>Clearing the entry</li> <li>Resetting the display to zero (P80!)</li> <li>CL plus MOD: Parameter list</li> <li>CL plus number: Selecting a parameter</li> <li>Clear parameter entry and show parameter number</li> </ul>
	<ul style="list-style-type: none"> <li>Algebraic sign</li> <li>Decreasing the parameter value</li> </ul>
	<ul style="list-style-type: none"> <li>Decimal point</li> <li>Increasing the parameter value</li> </ul>

Indicator	Meaning
<b>REF</b>	<p>If the decimal point is blinking: Display is waiting for the reference mark to be traversed.</p> <p>If the decimal point is not blinking: Reference mark was traversed—display unit saves the datum in nonvolatile memory</p> <p><b>Blinking:</b> Display is waiting for operator to press ENT or CL</p>
<b>inch</b>	Position values in inches
	Selected datum
<b>PRINT</b>	Measured value output with the MOD key
<b>SET</b>	<b>Blinking:</b> Display is waiting for entry values
<b>&lt; / = / &gt;</b>	<b>Sorting mode:</b> Measured value less than lower limit / within tolerances / greater than upper limit.
<b>MIN / MAX / DIFF / ACTL / START</b>	Nonfunctional

**Items Supplied with ND 231 B**

<b>ND 231 B</b>	Measured value display unit in benchtop housing
Two 11 $\mu\text{A}_{\text{pp}}$ encoder inputs	Id. Nr. 344 993-xx
<b>Power cable</b>	3 m (9.9 ft)
<b>User's Manual</b>	ND 231 B
<b>Adhesive inserts</b>	For stacking the ND 231 B



This Manual describes the ND 231 B measured value display units with software number

**349 797-01**

and higher. The software number is shown on a label on the back panel of the housing.

## Working with the Display Unit

<b>Position Encoders and Reference Marks</b>	<b>6</b>
<b>Switch-on, Traversing the Reference Points,</b>	<b>7</b>
<b>Datum Setting</b>	<b>8</b>
<b>Sorting and Tolerance Checking</b>	<b>9</b>
<b>Measured Value Output</b>	<b>10</b>
<b>Display Freeze</b>	<b>11</b>
<b>Error Messages</b>	<b>12</b>

## Installation and Specifications

<b>Rear Panel, Accessories</b>	<b>13</b>
<b>Mounting</b>	<b>14</b>
<b>Power Connection</b>	<b>15</b>
<b>Operating Parameters</b>	<b>16</b>
List of Operating Parameters	18
<b>Linear Encoders</b>	<b>22</b>
<b>Nonlinear Axis Error Compensation</b>	<b>25</b>
<b>RS-232-C/V.24 (X31) Data Interface</b>	<b>29</b>
<b>Switching Inputs and Outputs EXT (X41)</b>	<b>34</b>
<b>Locking the Keyboard</b>	<b>39</b>
<b>Displaying the Software Version</b>	<b>40</b>
<b>Distance-to-Go Mode</b>	<b>41</b>
<b>Specifications</b>	<b>42</b>
Dimensions	43

## Position Encoders and Reference Marks


The ND 231 B display unit is intended for use with photo-electrical linear encoders with sinusoidal signals: primarily for HEIDENHAIN **MT length gauges** with  $11 \mu\text{A}_{\text{pp}}$ .

These length gauges have **one** reference mark. The scales of other photoelectric linear encoders (see "Linear Encoders") can contain one reference mark or several *distance-coded* reference marks.

If there is an interruption of power, the relationship between the position of the length gauge and the displayed position value is lost. The reference marks on the position encoders and the REF reference mark evaluation feature enable the display unit to quickly reestablish this relationship again when the power is restored.


When a reference mark is crossed over, a signal is generated which identifies that position as a reference point. At the same time, the display unit restores the relationship between length gauge position and display values which you last defined by setting the datum.


If the linear encoders have **distance-coded** reference marks, you need only traverse a maximum of 20 mm to restore the datum (for a signal period of  $20 \mu\text{m}$ ).




Reference marks on linear encoders

## Switch-on, Traversing the Reference Marks

	<p><b>Turn on the power.</b> (Switch is located on rear panel).</p> <ul style="list-style-type: none"><li>• Units displays ND 231 B for 2 seconds.</li><li>• Unit displays ENT . . . CL <sup>1)</sup>.</li><li>• REF indicator is blinking.</li></ul>
ENT . . . CL	

	<p><b>Switch on the reference mark evaluation function.</b></p> <ul style="list-style-type: none"><li>• The position value that was last assigned to the reference mark position is displayed.</li><li>• REF indicator lights up.</li><li>• Decimal points are blinking.</li></ul>
5 , 6 9 7	

	<p><b>Traverse the reference marks.</b> Move the plunger until the display starts counting and the decimal points stop blinking. The display is now ready for operation.</p>
---	--

For automation purposes, crossing over the reference marks and the display ENT ... CL can be disabled with parameter P82.

## REF Mode

Crossing over the reference marks automatically switches the display to REF mode: The last assignment of display values to length gauge positions is stored in nonvolatile memory.

1) Press the CL key if you choose **not** to cross over the reference marks. Note that, in this case, the relationship between length gauge position and display value will be lost if the power is interrupted or if the unit is switched off.

## Datum Setting

The datum setting procedure assigns a display value to a known position. With the ND 200 series, you can set two separate datum points.

There are several ways to set the datum:

- Enter a numerical value, or
- Transfer a value from an operating parameter (see P79, P80), or
- By external signal



**Select datum 1 or 2.**

**5**

5


**Enter numerical value** (here, 5).




**Confirm the entered numerical value.**

You can switch between datums 1 and 2 as desired. Datum 2 can be used, for example, for working with incremental dimensions.

When you switch back to datum 1, the display unit resumes display of the MT's actual position.



Without datum setting: unknown assignment of measured values to positions



After datum setting: Assignment of measured values to positions



## Sorting and Tolerance Checking

In the sorting and tolerance checking mode, the display unit compares the displayed value with the programmed upper and lower sorting limits. The sorting and tolerance checking mode is enabled and disabled with operating parameter **P17**.

### Entering sorting limits


Sorting limits are entered in operating parameters **P18** and **P19** (see "Operating Parameters").

### Sorting signals

The display indicators and switching outputs at D-sub connection EXT (X41, see applicable section) sort the display value into one of three classes.

Display	Meaning
=	Measured value is within sorting limits
<	Measured value is smaller than lower sorting limit
>	Measured value is greater than upper sorting limit

Operating parameters for sorting and tolerance checking	
P17 SORT	Sorting ON/OFF
P18 L. LIMIT	Lower sorting limit
P19 U. LIMIT	Upper sorting limit



Example: Upper sorting limit = 26.02 mm  
Lower sorting limit = 26.00 mm

## Measured Value Output




For technical information on the RS-232-C/V.24 data interface (X31), information on the data format, etc., see the chapter "RS-232-C/V.24 Interface (X31)."

Measured values can be output over the RS-232-C/V.24 interface (X31), for example to a printer or PC.

There are several ways to start measured value output:

- ▶ Press the MOD key (note the parameter setting P86).  
**or**
- ▶ Input the command STX (Ctrl B) over the RXD input of the RS-232-C/V.24 interface (X31);  
**or**
- ▶ Input a signal for measured data output (Pulse or Contact) at the D-sub connection EXT (X41).




The RS-232-C/V.24 interface (X31) enables you to connect a printer or a PC to your display unit

## Display Freeze

With the latch command, the display can be stopped for any period of time. The internal counter remains active. Parameter P23 selects the “display freeze” mode and offers three settings:

- **Concurrent display**, no display freeze—the display value is the current measured value.
- **Frozen display**—display value is frozen and is updated with each signal for measured value output.
- **Frozen/concurrent display**—display remains frozen as long as the latch signal is present; after the signal, the display resumes continuous display of the current measured values.



## Error Messages

Display	Problem
RS232 FAST	Command for measured value output followed too quickly by another. <sup>1)</sup>
SIGNAL X1	Encoder signal is too weak. The scale may be contaminated. <sup>1)</sup>
DSR.MISSING	The connected device has not sent a DSR signal. <sup>1)</sup>
REF. ERR. X1	The spacing of the reference marks as defined in P43 is not the actual spacing. <sup>1)</sup>
FORMAT ERR.	Data format, baud rate, etc. do not match. <sup>1)</sup>
FRQ.ERR. X1	Input frequency too high for encoder input. Traversing speed may be too fast. <sup>1)</sup>
MEMORY ERR.	Checksum error: Check the datum, operating parameters and compensation values for nonlinear axis error compensation. If this error recurs, contact your service agency!

<sup>1)</sup> These errors are important for the attached device. The error signal (pin 19) at D-sub connection EXT is active.

### Other Error Displays

If "OVERFLOW" appears, the measured value is too large or too small:

- ▶ Set a new datum.
- or**
- ▶ Move the axis back.

If **all sorting signals light up**, the upper sorting limit is smaller than the lower limit:

- ▶ Change operating parameters P18 and/or P19.

### To clear error messages:

When you have removed the cause of the error:

- ▶ Clear the error message with the CL key.

## Rear Panel



Ports X1, X2, X31 and X41 comply with the recommendations in EN 50 178 for separation from line power.

### Encoder input X1

HEIDENHAIN flange socket	9-pin
Input signals	$\sim$ 11 $\mu$ A <sub>PP</sub>
Maximum encoder cable length	30 m (98.5 ft)
Maximum input frequency	100 kHz

### RS-232-C/V.24 data interface (X31)

25-pin D-sub connection (female)


### Switching inputs and outputs EXT (X41)

25-pin D-sub connection (male)

## Accessories


### Connecting elements

<b>Connector</b> (female)	25-pin for D-sub connection X41 Id. Nr. 249 154-ZY
<b>Connector</b> (male)	25-pin for D-sub connection X31 Id. Nr. 245 739-ZY
<b>Data interface cable, complete</b>	3 m (9.9 ft), 25-pin for D-sub connection X31, Id. Nr. 274 545-01




## Mounting

You can fasten the **ND 231 B** from below by using M4 screws (see illustration at right).



Hole positions for mounting the ND display unit

ND 231 B display units are stackable. Adhesive plug-in feet (supplied with your unit) prevent the stacked units from being moved out of place.



Alternatives of stacking the display units

## Power Connection

The rear panel of the ND 281 B contains a connecting jack for a power cord with Euro connector (power cord supplied with the delivery).

**Minimum cross section of the power cord:** 0.75 mm<sup>2</sup>

**Power supply:** 100 Vac to 240 Vac (–15% to +10%)  
50 Hz to 60 Hz (±2 Hz)

A voltage selector is therefore not necessary.



### **Danger of electrical shock!**

Unplug the power cord before opening the housing. Connect the grounding conductor. Do not interrupt the grounding conductor.



### **Danger to internal components!**

Do not engage or disengage any connections while the unit is under power. Use only original replacement fuses.



To increase noise immunity, connect the ground terminal on the rear panel to the central ground point of the machine.  
(Minimum cross-section: 6 mm<sup>2</sup>)

## Operating Parameters

Operating parameters allow you to modify the operating characteristics of your ND display unit and define the evaluation of the encoder signals.

Operating parameters are designated by:

- the letter P,
- a two-digit parameter number, and
- an abbreviation.

**Example:** P01 INCH

The **factory settings of the operating parameters** are indicated in the parameter list (see “List of Operating Parameters”) in boldface type.

Parameters consist of “user parameters” and “protected operating parameters,” which can only be accessed by entering a code number.

### User parameters


User parameters are operating parameters that can be changed **without** entering the code number:

P00 to P30, P50, P51, P79, P86, P98



The functions of the individual user parameters are detailed in the list of operating parameters (see “List of Operating Parameters”).

### To access a user parameter ...



... after switching on the display:


While ENT ... CL is displayed: 	Display first user parameter.
---	-------------------------------

... during operation:

Together:  	Display first user parameter.
--	-------------------------------

### To go directly to a user parameter:

Together:  	Press and hold CL while entering the first digit of the parameter number (here, 1).
--	---

	Enter the second digit of the parameter number (here, 9). The display shows the selected user parameter.
---	---



## Code number for changing protected operating parameters

If you wish to change protected operating parameters, you must first enter the **code number 95 148**:

- Select the user parameter P00 CODE.
- Enter the code number 9 51 48.
- Confirm entry with ENT.

Parameter P30.1 appears on the display. By paging through the list of operating parameters you can display—and, if necessary, change—each protected operating parameter and, of course, each user parameter.



Once you have entered the code number, the protected operating parameters remain accessible until the display unit is switched off.

## Functions for changing the operating parameters

Function	Key
Page forward in the list of operating parameters	
Page backward in the list of operating parameters	
Reduce parameter value	
Increase parameter value	
Correct entry and display parameter designations	
Confirm change or numerical entry, leave list of operating parameters	

A changed parameter is stored as soon as you

- leave the list of operating parameters
- or**
- page forward or backward after the change.

## List of Operating Parameters

Parameter	Settings / Function
P00 CODE	Enter the <b>code number 9 51 48</b> to change the protected operating parameters
P01	<b>Units of measurement 1)</b> Display in millimeters <b>MM</b> Display in inches <b>INCH</b>
P06 DISPL.	<b>Displayed information</b> Signals from encoder at X1 <b>DISPLAY X1</b> Signals from encoder at X2 <b>DISPLAY X2</b> Sum display X1 + X2 <b>X1 ADD. X2</b> Difference display X2 – X2 <b>X1 SUB. X2</b>
P11 SCL	<b>Scaling factor</b> Scaling factor on <b>SCALING ON</b> Scaling factor off <b>SCALNG. OFF</b>
P12.1 SCL	<b>Scaling factor X1</b> Enter a numerical value 0.100000 < P12 < 9.999999 Default setting: <b>1.000000</b>
P12.2 SCL	<b>Scaling factor X2</b> Enter a numerical value 0.100000 < P12 < 9.999999 Default setting: <b>1.000000</b>

Parameter	Settings / Function
P17 SORT	<b>Sorting and tolerance checking</b> Sorting and tol. checking ON <b>SORT ON</b> Sorting and tol. checking OFF <b>SORT OFF</b>
P18 L.LIMIT	<b>Lower limit</b> for sorting
P19 U.LIMIT	<b>Upper limit</b> for sorting
P23 DISPL.	<b>Display stop for measured value output</b> <b>Concurrent display</b> , no display freeze; the display value is the current actual value <b>DISPL. ACTL.</b> <b>Frozen display</b> ; hold display until next measured value output <b>DISPL. HOLD</b> <b>Frozen/concurrent display</b> ; freeze display as long as Pulse/Contact for measured value output is present <b>DISPL. STOP</b>
P30.1 DIR	<b>Counting direction X1</b> Positive counting direction with positive direction of traverse <b>DIRECT. POS</b> Negative counting direction with positive direction of traverse <b>DIRECT. NEG</b>
P30.2 DIR	<b>Counting direction X2</b> Positive counting direction with positive direction of traverse <b>DIRECT. POS</b> Negative counting direction with positive direction of traverse <b>DIRECT. NEG</b>



Parameter	Settings / Function
P43.1 REF	<b>Reference marks X1</b> One reference mark <b>SINGLE REF.</b>
	Distance-coded with 500 • SP (SP: signal period) <b>500 SP</b>
	Distance-coded with 1000 • SP (e.g. for HEIDENHAIN LS ...C) <b>1000 SP</b>
	Distance-coded with 2000 • SP <b>2000 SP</b>
	Distance-coded with 5000 • SP <b>5000 SP</b>
P43.2 REF	<b>Reference marks X2</b> One reference mark <b>SINGLE REF.</b>
	Distance-coded with 500 • SP (SP: signal period) <b>500 SP</b>
	Distance-coded with 1000 • SP (e.g. for HEIDENHAIN LS ...C) <b>1000 SP</b>
	Distance-coded with 2000 • SP <b>2000 SP</b>
	Distance-coded with 5000 • SP <b>5000 SP</b>
P44.1 REF	<b>Reference mark evaluation</b> Evaluate the reference mark <b>REF. X1 ON</b>
	Do not evaluate the reference mark <b>REF. X2 OFF</b>

Parameter	Settings / Function
P44.2 REF	<b>Reference mark evaluation <sup>1)</sup></b> Evaluate the reference mark <b>REF. X2 ON</b>
	Do not evaluate the reference mark <b>REF. X2 OFF</b>
P45.1 ALARM	<b>Encoder monitoring X1</b> No monitoring <b>ALARM OFF</b>
	Monitor the frequency <b>FREQUENCY</b>
	Monitor contamination <b>CONTAMINAT.</b>
	Contamination + frequency <b>FRQ. + CONT.</b>
P45.2 ALARM	<b>Encoder monitoring X2</b> No monitoring <b>ALARM OFF</b>
	Monitor the frequency <b>FREQUENCY</b>
	Monitor contamination <b>CONTAMINAT.</b>
	Contamination + frequency <b>FRQ. + CONT.</b>
P50 RS232	<b>Baud rate</b> 110 / 150 / 300 / 600 / 1200 / 2400 / 4800 / <b>9600</b> / 19 200 / 38 400 baud
	<b>Additional blank lines</b> <b>during data output</b> <b>BK LINE 1</b> 0 ≤ P51 ≤ 99 Default setting: <b>1</b>

<sup>1)</sup> If an encoder input is unoccupied, it must be deactivated.  
The settings go into effect after switch-on.

Parameter	Settings / Function
P62 A1	<b>Trigger limit 1</b>
P63 A2	<b>Trigger limit 2</b>
P79 PRESET	<b>Value for datum point</b> Enter numerical value for datum setting over switching input or with ENT key
P80 ENT-CL	<b>Set display</b> No set/Set with CL/ENT <b>CL-ENT OFF</b> Zero reset with CL setting disabled with ENT <b>CL . . . . . ON</b> Zero reset with CL and set with ENT to value selected in P79 <b>CL-ENT ON</b>
P82 DISPL.ON	<b>Message after switch-on</b> ENT . . . CL message <b>MESSAGE ON</b> No message <b>MESSG. OFF</b>
P85 EXT.REF	<b>External REF</b> REF over D-sub port EXT <b>EXT.REF ON</b> No REF over D-sub port EXT <b>EXT.REF OFF</b>

Parameter	Settings / Function
P86 MOD	<b>Print via MOD key</b> PRINT via MOD disabled <b>PRINT OFF</b> PRINT via MOD enabled <b>PRINT ON</b>
P98 LANGUA.	<b>Conversational language</b> German <b>LANGUAGE D</b> English <b>LANGUAGE GB</b> French <b>LANGUAGE F</b> Italian <b>LANGUAGE I</b> Dutch <b>LANGUAGE NL</b> Spanish <b>LANGUAGE E</b> Danish <b>LANGUAGE DK</b> Swedish <b>LANGUAGE S</b> Finnish <b>LANGUAGE FI</b> Czech <b>LANGUAGE CZ</b> Polish <b>LANGUAGE PL</b> Hungarian <b>LANGUAGE H</b> Portuguese <b>LANGUAGE P</b>

## Linear Encoders

The ND 231 B display unit is designed for use together with photoelectrical encoders with  $11 \mu\text{A}_{\text{PP}}$  sinusoidal signals.

### Display step with linear encoders

You can select a specific display step by adapting the following operating parameters:

- Subdivision (P31)
- Counting mode (P33)
- Decimal places (P38)

### Example

Linear encoder with a signal period of  $10 \mu\text{m}$

Desired display step ..... 0.000 5 mm

Subdivision (P31) ..... 10

Counting mode (P33) ..... 5

Decimal places (P38) ..... 4

The tables on the following pages will help you to select the appropriate parameter settings.

## Recommended parameter settings for HEIDENHAIN linear encoders with 11 $\mu\text{A}_{pp}$ signals

Model	Signal periods in $\mu\text{m}$ P31	Reference marks P 43	Millimeters			Inches		
			Display step in mm	Count mode P 33	Decimal places P 38	Display step in inches	Count mode P 33	Decimal places P 38
			CT MT xx01	2	Single	0.0005	5	4
LIP 401A/401R	Single	0.0002	2		4	0.00001	1	5
			0.0001	1	4	0.000005	5	6
			0.00005	5	5	0.000002	2	6
			<i>Recommd. only for LIP 401</i>					
			0.00002	2	5	0.000001	1	6
			0.00001	1	5	0.0000005	5	7
			0.000005	5	6	0.0000002	2	7
LF 103/103C LF 401/401C LIF 101/101C LIP 501/501C	4	Single/5000	0.001	1	3	0.00005	5	5
LIP 101		Single	0.0005	5	4	0.00002	2	5
			0.0002	2	4	0.00001	1	5
			0.0001	1	4	0.000005	5	6
			0.00005	5	5	0.000002	2	6
			<i>Recommd. only for LIP 101</i>					
			0.00002	2	5	0.000001	1	6
			0.00001	1	5	0.0000005	5	7
MT xx	10	Single	0.0005	5	4	0.00002	2	5
			0.0002	2	4	0.00001	1	5
			0.0001	1	4	0.000005	5	6
LS 303/303C LS 603/603C	20	Single/1000	0.01	1	2	0.0005	5	4
			0.005	5	3	0.0002	2	4

**Recommd. parameter settings for HEIDENHAIN linear encoders with 11  $\mu\text{A}_{pp}$  signals (continued)**

Model	Signal period in $\mu\text{m}$ P31	Reference marks P 43	Millimeters			Inches		
			Display step in mm	Count mode	Decimal places	Display step in inches	Count mode	Decimal places
				P 33	P 38		P 33	P 38
LS 106/106C LS 406/406C LS 706/706C	20	Single/1000	0.001	1	3	0.00005	5	5
ST 1201			0.0005	5	4	0.00002	2	5
LB 302/302C LIDA 10x/10xC	40	Single/2000	0.005	5	3	0.0002	2	4
			0.002	2	3	0.0001	1	4
			0.001	1	3	0.00005	5	5
			0.0005	5	4	0.00002	2	5
			<i>Recommd. only for LB 302</i>					
	0.0002	2	4	0.000001	1	5		
	0.0001	1	4	0.0000005	5	6		
LB 301/301C	100	Single/1000	0.005	5	3	0.0002	2	4
			0.002	2	3	0.0001	1	4
			0.001	1	3	0.00005	5	5
LIM 102	12800	Single	0.1	1	1	0.005	5	3
			0.05	5	2	0.002	2	3

**Example**

Your length gauge: MT 101  
 Desired display step: 0.0005 mm (0,5  $\mu\text{m}$ )  
 Parameter settings: P01 = mm, P43 = single, P31 = 10, P33 = 5, P38 = 4



## Nonlinear Axis Error Compensation



If you want to use the nonlinear axis error compensation feature, you must:

- Activate the feature with operating parameter 40 (see “Operating Parameters”),
- Traverse the reference marks after switching on the display unit,
- enter a compensation value table

Your machine may have a nonlinear axis error due to factors such as axis sag or leadscrew errors. Such deviations are usually measured with a comparator measuring system (such as the HEIDENHAIN VM 101).

An axis can be error-compensated only with respect to an error-causing axis. A compensation table with a total of up to 64 compensation values can be entered for every axis.

You select the compensation table through P00 CODE and by entering the code number 10 52 96 (see Operating Parameters).

### Ascertaining the compensation values

To ascertain the compensation values (e.g. with a VM 101) you must select the compensation table and then press the “-” key to select the REF display.

The letter “R.1” or “R.2” at the left of the display indicates that the displayed position value is given with respect to the reference mark. If “R.1” or “R.2” blinks, you must traverse the reference mark.

### Entries in the compensation value table

- Axis to be error-compensated: X1 or X2
- Error-causing axis: X1 or X2
- Datum:

Here you enter the point at which the compensation is to begin. This point indicates the absolute distance to the reference point.



Do not change the datum after measuring the axis error and before entering the axis error into the compensation table.

- Spacing of the compensation points:  
The spacing of the compensation points is expressed as:  
$$\text{Spacing} = 2^x [\mu\text{m}].$$

Enter the value of the exponent  $x$  into the compensation value table.

Minimum input value: 6 (= 0.064 mm)

Maximum input value: 20 (= 1048.576 mm)

**Example:** 900 mm traverse with 15 compensation points  
==> 60.000 mm spacing between points.

Nearest power of two:  $2^{16} = 65.536$  mm (see “Table for determining the point spacing”)

Input value in the table: 16

- Compensation value:  
You enter the measured compensation value (in millimeters) for the displayed compensation point. Compensation point 0 always has the value 0 and cannot be changed.

**Table for determining the point spacing**


Exponent	Point spacing	
	in mm	in inches
6	0.064	0.0023"
7	0.128	0.0050"
8	0.256	0.0100"
9	0.512	0.0200"
10	1.024	0.0403"
11	2.048	0.0806"
12	4.016	0.1581"
13	8.192	0.3225"
14	16.384	0.6450"
15	32.768	1.290"
16	65.536	2.580"
17	131.072	5.160"
18	262.144	10.32"
19	524.288	20.64"
20	1048.576	41.25"

## Selecting the compensation table, entering an axis correction

<b>CL</b> Together with <b>MOD</b>	Select the operating parameters.
<b>1/4</b>	Select P00 CODE.
<b>P00 CODE</b>	
<b>1 0 5 2</b> <b>9 6 ENT</b>	Enter the code number 10 52 96, confirm with ENT.
<b>AXIS X1</b>	
<b>• MOD</b>	Select the axis whose error is to be compensated (X1 or X2). Press MOD to go to the next input box.
<b>X1 FCT. X1 or X1 FCT X2</b>	
<b>• MOD</b>	Select the error-causing axis (X1 or X2). Press MOD to select the datum.
<b>DATUM X1 or X2</b> (shown for approx. two seconds)	
<b>2 7 MOD</b>	Enter the active datum for the error on the axis to be compensated, e.g. 27 mm. Press MOD to select the next input box.

<b>SPACING</b>	
<b>1 0</b> 4 x <b>MOD</b>	Enter the spacing of the compensation points on the axis to be corrected, for example $2^{10} \mu\text{m}$ (equals 1.024 mm). Press MOD four times to select COMP. NR. 01. (You cannot enter values in the POS. NR. 00, COMP. NR. 00 and POS. NR. 01 boxes.)
<b>COMP. NR. 01</b>	
<b>0 . 0 1</b> 2 x <b>MOD</b>	Enter the associated compensation value, e.g. 0.01 mm. Press MOD twice to select COMP. NR. 02. (You cannot enter any values in the POS. NR. 02 box).
<b>COMP. NR. 02</b>	
<b>0 . 0 2</b> 2 x <b>MOD</b>	Enter all further compensation points. If you want so select a compensation point directly, press CL and simultaneously enter the desired compensation point number.
<b>ENT</b>	Conclude entry.

## Deleting a compensation value table




## RS-232-C/V.24 Data Interface (X31)

The RS-232-C/V.24 interface (X31) of your display unit enables you to output measured data in ASCII format, for example to a printer or PC.


### Connecting cable

You can use a connecting cable with full wiring (figure at upper right) or simplified wiring (below right). A cable with full wiring is available from HEIDENHAIN (Id. Nr. 274 545-...). On this type of cable, pin 6 and pin 8 are additionally connected over a jumper.

**Maximum cable length:** 20 m (66 ft)



Full wiring



Simplified wiring

## Pin layout RS-232-C/V.24 (X31)

Pin	Signal	Assignment
1	CHASSIS GND	Chassis ground
2	TXD	Transmitted data
3	RXD	Received data
4	RTS	Request to send
5	CTS	Clear to send
6	DSR	Data set ready
7	SIGN. GND	Signal ground
8 to 19	-	<i>Not assigned</i>
20	DTR	Data terminal ready
21 to 25	-	<i>Not assigned</i>

## Levels for TXD and RXD

Logic level	Voltage level
Active	- 3 V to - 15 V
Not active	+ 3 V to + 15 V

## Levels for RTS, CTS, DSR and DTR

Logic level	Voltage level
Active	+ 3 V to + 15 V
Not active	- 3 V to - 15 V

## Data format and control characters

**Data format**            1 start bit  
                                  7 data bits  
                                  Even parity bit  
                                  2 stop bits

**Control characters**    Call measured value: STX (Ctrl B)  
                                  Interrupt DC3 (Ctrl S)  
                                  Continue DC1 (Ctrl Q)  
                                  Interrogate error message: ENQ (Ctrl E)

## Example: Data sequence during measured value output

Measured value = - 5.23 mm

The measured value is within the sorting limits ( = ) and is the current value ( A ) of a series of measurements.

## Measured value output

-	5	.	2	3			=	A	<	C	R	>	<	L	F	>
---	---	---	---	---	--	--	---	---	---	---	---	---	---	---	---	---

- ①                    ②                    ③                    ④                    ⑤                    ⑥                    ⑦                    ⑧
- ① Algebraic sign
  - ② Numerical value with decimal point (10 characters on the whole, leading zeros are output as blank spaces.)
  - ③ Blank space
  - ④ Unit: Blank space = mm; " = inch; ? = fault
  - ⑤ Sorting status (<, >, =; ? if P18 > P19)  
**or** blank space
  - ⑥ Axis designation (1 = X1, 2 = X2, A = X1 + X2, S = X1 - X2)
  - ⑦ CR (carriage return)
  - ⑧ LF (line feed)

## Operating parameters for measured value output

Parameter	Function
P50 RS232	Baud rate
P51 RS232	Number of additional blank lines for measured value output

## Display freeze during measured value output

In operating parameter P23, you can specify how the measured value output signal will affect the display unit.

Display freeze during measured value output	P23
---	-----

**Concurrent display**, no display freeze: The display value is the current measured value DISPL. ACTL.

**Frozen display**: Display is stopped (frozen) and updated by every measured value output signal DISPL. HOLD

**Frozen/concurrent display**: Display is frozen as long as a measured value output signal is present DISPL. STOP

## Measured value output via PRINT function

➤ Press the MOD key (note parameter setting P86).

## Duration of measured value transfer

$$t_D = \frac{187 + (11 \cdot \text{number of blank lines})}{\text{baud rate}} \text{ [ s ]}$$

### Measured value output after signal through the "Contact" or "Pulse" inputs

To start measured value output through the EXT interface (X41) you can either:


- Close the "Contact" input (pin 23 on X41) against 0 V, for example with a simple switch (make contact);  
**or**
- Close the "Pulse" input (pin 22 on X41) against 0 V, for example by triggering the input with a TTL logic device (such as SN74LSxx).

### Characteristic times for measured value output


Process	Time
Minimum duration of "Contact" signal	$t_e \geq 7 \text{ ms}$
Minimum duration of "Pulse" signal	$t_e \geq 1.5 \mu\text{s}$
Storage delay after "Contact"	$t_1 \leq 5 \text{ ms}$
Storage delay after "Pulse"	$t_1 \leq 1 \mu\text{s}$
Measured value output after	$t_2 \leq 57 \text{ ms}$
Regeneration time	$t_3 \geq 0$

### Duration of measured value transfer

$$t_D = \frac{187 + (11 \cdot \text{number of blank lines})}{\text{baud rate}} \text{ [s]}$$



Triggering the "Contact" and "Pulse" inputs at D-sub connection EXT (X41)



Signal transit times for measured value output after "Pulse" or "Contact"



### Measured value output after "STX" signal (Ctrl B)

If the display unit receives the control character STX (Ctrl B) over the RS-232-C/V.24 interface (X31), it outputs the current measured value over the interface.

- Transfer the control character Ctrl B over the RXD line of the RS-232-C/V.24 interface (X31).

### Characteristic times for measured value output


Process	Time
Storage delay	$t_1 \leq 1 \text{ ms}$
Measured value output after	$t_2 \leq 50 \text{ ms}$
Regeneration time	$t_3 \geq 0$

### Duration of measured value transfer

$$t_D = \frac{187 + (11 \cdot \text{number of blank lines})}{\text{baud rate}} \text{ [s]}$$

```
10 L%=18
20 CLS
30 PRINT "V.24/RS-232-C"
40 OPEN "COM1:9600,E,7" AS#1
50 PRINT #1, CHR$(2);
60 IF INKEY$<>" THEN 130
70 C%=LOC(1)
80 IF C%<L% THEN 60
90 X$=INPUT$(L%,#1)
100 LOCATE 9,1
110 PRINT X$;
120 GOTO 50
130 END
```

BASIC program for measured value output with "Ctrl B"



Propagation times for measured value output after "Ctrl B"

## Switching Inputs and Outputs EXT (X41)



### Danger to internal components!

Voltage sources for external circuitry must conform to the recommendations in EN 50 178 for low-voltage electrical separation. Connect inductive loads only with a quenching diode parallel to the inductance.



### Only use shielded cable!

Connect the shield to the connector housing.

## Outputs at D-sub connection EXT (X41)

Pin	Function
14	Display value is zero
15	Measured value $\geq$ trigger limit A1 (P62)
16	Measured value $\geq$ trigger limit A2 (P63)
17	Measured value $<$ lower sorting limit (P18)
18	Measured value $>$ upper sorting limit (P19)
19	Error (see "Error Messages")

## Inputs at D-sub connection EXT (X41)

Pin	Function
1, 10	0 V
2	Reset display to zero, clear error message
3	Set display to the value selected in P79
4	Ignore reference mark signals
5	Start series of measurements <sup>1)</sup>
6	Externally select display value for series of measurements <sup>1)</sup>
7	Display MIN value of series of measurements <sup>1)</sup>
8	Display MAX value of series of measurements <sup>1)</sup>
9	Display difference MAX – MIN <sup>1)</sup>
22	Pulse: Output measured value
23	Contact: Output measured value
25	Enable or disable REF mode (current REF status is changed)
12, 13, 24	<i>Do not assign</i>
11, 20, 21	<i>Vacant</i>

## Inputs

### Input signals

Internal pull-up resistor 1 k $\Omega$ , active with low level


Trigger by making contact against 0 V **or**  
by low level signal over TTL logic device

Delay for set/zero reset:  $t_d \leq 2$  ms

Minimum pulse duration for all signals:  $t_{min} \geq 30$  ms

### Signal level of inputs

Status	Level
High	$+ 3.9 \text{ V} \leq U \leq + 15 \text{ V}$
Low	$- 0.5 \text{ V} \leq U \leq + 0.9 \text{ V}; I \leq 6 \text{ mA}$



## Outputs

### Output signals


Open collector outputs, active with low level

Delay until signal output:  $t_d \leq 30$  ms

Signal duration of zero signal, trigger limit A1, A2:  $t_0 \geq 180$  ms

### Signal level of outputs

Status	Level
High	$U \leq + 32 \text{ V}; I \leq 10 \mu\text{A}$
Low	$U \leq + 0.4 \text{ V}; I \leq 100 \text{ mA}$



### Setting and zero resetting the display

With an external signal, you can set the display to the value selected in parameter P79 (pin 3) or reset each axis to zero (pin 2).

### Enabling and disabling REF mode

Operating parameter P85 allows you to activate the input (pin 25) which will be used for setting the display externally to REF mode when the unit is switched on or when the power is restored after an interruption. The next signal deactivates REF mode again (switchover function).

### Ignoring reference mark signals

If this input (pin 4 or pin 24) is active, the display will ignore all reference mark signals. A typical application of this function is for measuring lengths with a rotary encoder and spindle; in this case, a cam switch releases the reference mark signal at a preset position.

### Selecting the display information

You can select the display information of the ND 231 B

- through switching inputs (see D-sub connection EXT) or
- with the operating parameters P06 (see Operating Parameter list).

If you use the switching inputs, the setting of P06 has no influence on the display information.

If none of the inputs for the selection of display information (pin 6 to pin 9) is active, or if more than one is active, then the settings of the operating parameter P06 apply:

- Position if the encoder on X1: P06 = DISPLAY X1
- Position if the encoder on X2: P06 = DISPLAY X2
- Sum display: P06 = X1 ADD. X2
- Difference display: P06 = X1 SUB. X2

## Switching signals

As soon as the trigger points defined in parameters are reached, the corresponding outputs (pins 15, 16) are activated. You can set up to two trigger points. The switching point "zero" has a separate output (see "Zero crossover").




## Signals for sorting and tolerance checking

If the sorting limits defined in parameters are exceeded, the corresponding outputs (pins 17, 18) are activated.

Signals	Operating parameters	Pin
Switching signals	P62, switching limit 1 P63, switching limit 2	15 16
Sorting signals	P18, lower sorting limit P19, upper sorting limit	17 18

## Zero crossover

The display value "zero" activates the corresponding output (pin 14). Minimum signal duration is 180 ms.




Time curve of signal at pin 15 for trigger limit (A1) = 5 mm ,  $t_d \leq 30$  ms

### Switching signal for errors

The display unit permanently monitors functions such as measuring signal, input frequency, and data output, and displays an error message if it detects an error.

If errors occur that seriously influence measurement or data output, the display unit activates a switching output. This feature allows monitoring of automated processes.



## Locking the Keypad

You can disable or re-enable the keypad by entering the code number 24 65 84:

- Select the user parameter `P00 CODE` (see “Operating Parameters”).
- Enter the code number 24 65 84.
- Confirm the entry with ENT.
- With the “•” or “-” key, select `KEYS ON` or `KEYS OFF`.
- Confirm your selection with ENT.

If the keypad is locked, you can select only the datum or `P00 CODE` through the MOD key.

## Displaying the Software Version

To display the software version of the display unit, enter the code number 66 55 44:

- Select the user parameter P00 CODE.
- Enter the code number 66 55 44.
- Confirm your entry with ENT.
- The display unit shows the software number.
- With the “-” key you can switch the display to the date of issue.
- To exit the software version display mode, press ENT.



## Distance-to-Go Display Mode <sup>1)</sup>

Normally, the display shows the actual position of the encoder. However, it is often more helpful to display the remaining distance to an entered nominal position—especially when you are using the display unit for machine tools and automation purposes. You can then position simply by traversing to display value zero.

You can access the distance-to-go display by entering the **code number 246 582**.


Display	Meaning
DELTA ON	Distance-to-go display active
DELTA OFF	Distance-to-go display not active

### “Traversing to zero” with distance-to-go display

- Select datum point 2.
- Enter the nominal position.
- Move the axis until the display value is zero.

## Function of switching outputs A1 and A2

In the distance-to-go mode, switching outputs A1 (pin 15) and A2 (pin 16) have a different function: they are symmetrical to the display value zero. For example, if a switching point of 10 mm is entered in P62, output A1 switches at both +10 mm and -10 mm. The figure below shows output signal A1 when approaching zero from the negative direction.






Time curve of a signal for switching limit (A1) = 10 mm ,  $t_{d1} \leq 30$  ms,  $t_{d2} \leq 180$  ms

## Specifications

<b>Housing</b>	<b>ND 231 B</b> Benchtop design, cast-metal housing (W · H · D) 239 mm · 84.6 mm · 224 mm
<b>Operating temperature</b>	0° to 45° C (32° to 113° F)
<b>Storage temperature</b>	-20 °C to 70 °C (-4 °F to 158 °F)
<b>Weight</b>	Approx. 1.5 kg (3.3 lb)
<b>Relative humidity</b>	< 75% annual average < 90% in rare cases
<b>Power supply</b>	Primary-clocked power supply 100 Vac to 240 Vac (-15% to +10%) 50 Hz to 60 Hz (± 2 Hz)
<b>Line fuse</b>	F 1 A inside the housing
<b>Power consumption</b>	8 W (typically)
<b>Electromagnetic compatibility</b>	Class B according to EN 55022

<b>Noise immunity</b>	As per VDE 0843 Parts 2 and 4, severity 4
<b>Protection</b>	IP40 according to IEC 529
<b>Encoder inputs</b>	For encoders with sinusoidal output signals (11 $\mu$ A <sub>PP</sub> ); Reference mark evaluation for distance- coded and single reference marks
<b>Input frequency</b>	X1 and X2: Max. 100 kHz for 30 m cable length
<b>Display step</b>	Adjustable
<b>Datum points</b>	Two
<b>Functions</b>	<ul style="list-style-type: none"> <li>• Sorting and tolerance checking</li> <li>• Switching and sorting signals</li> <li>• Set display and reset display to zero with external signal</li> <li>• Measured value output</li> </ul>
<b>RS-232-C/V.24 Interface</b>	Baud rates: 110, 150, 300, 600, 1200, 2400, 4800, 9600, 19 200, 38 400 baud

## ND 231 B: Dimensions in mm/inches




# HEIDENHAIN

---

## **DR. JOHANNES HEIDENHAIN GmbH**

Dr.-Johannes-Heidenhain-Straße 5


**83301 Traunreut, Germany**


 + 49/86 69/31-0


 + 49/86 69/50 61

e-mail: [info@heidenhain.de](mailto:info@heidenhain.de)

---

 **Service** + 49/86 69/31-12 72

 TNC-Service + 49/86 69/31-14 46

 + 49/86 69/98 99

e-mail: [service@heidenhain.de](mailto:service@heidenhain.de)

---

<http://www.heidenhain.de>

## **HEIDENHAIN (G.B.) Limited**

200 London Road, Burgess Hill

West Sussex RH15 9RD, Great Britain

 (01444) 24 77 11

 (01444) 87 00 24