

## CONTENTS

<b>2</b>	<b>SPECIFICATIONS</b>
<b>3</b>	<b>CONNECTIONS</b>
<b>4</b>	<b>MOUNTING</b>
4	Arm Mounting (Non-adjustable)
4	Arm Mounting (Adjustable)
5	Face Mounting (Adjustable)
5	Lathe Mounting (Adjustable)
<b>6</b>	<b>OPERATION</b>
6	Understanding the Displays
6	Using the Keypad
<b>7</b>	<b>STANDARD FUNCTIONS</b>
7	Setting the Datum for Each Axis
7	Using Digifind
7	Using Centerfind
<b>8</b>	<b>SETUP</b>
8	Using Setup Mode
9	Machine Type
9	Unit Information Mode
9	Encoder
10	Radius / Diameter
10	Direction
10	Error Compensation
11	Segmented Error Compensation
12	Linear Error Compensation
13	RS232 Communication
15	Axis Summing
15	Zero Approach
15	Taper Display Axis
16	Add / Delete Function
16	Reset
16	Store
<b>17</b>	<b>SPECIAL FUNCTIONS</b>
17	The Menu Function
<b>18</b>	<b>MILL FUNCTIONS</b>
18	Bolt Hole Circle
20	Arc Contouring
22	Line Hole
24	Polar Coordinates
<b>25</b>	<b>LATHE FUNCTIONS</b>
25	Taper
26	Tool Offsets
28	Summing
29	Vectoring
<b>30</b>	<b>GENERIC FUNCTIONS</b>
30	Sub-Datums and Jobs
<b>33</b>	<b>TROUBLESHOOTING</b>
<b>33</b>	<b>CLEANING</b>

## NOTES

## SPECIFICATIONS

**Electrical****EMC and Low Voltage Compliance**

BS EN 55022:1998 Class B  
BS EN 55024:1998

**Power Supply Unit (supplied)**

100 - 240V (47 - 63Hz)  
External switch-mode  
Conforms to Low Voltage Directive  
EN 60 950:1992/  
A1:1993/ A2:1994/ A3:1996/ A4:1997

**Physical****Height**

265mm (10.43")

**Width**

180mm (7.09")

**Depth (not including connectors)**

50mm (1.97")

**Weight**

2.9kg (6.38lb)

**Environmental****Operating Temperature**

0 to 45°C

**Storage Temperature**

-20 to 70°C

**Environmental Conditions**

Indoor Use, IP20 (IEC 529)

**Relative Humidity**

Maximum 80% for temperatures up to 31°C  
decreasing linearly to 33% at 45°C

**Disposal**

At the end of its life, the **C80** system should be disposed of in a safe manner applicable to electronic goods.



**DO NOT BURN.**

The casework is suitable for recycling. Please consult local regulations on disposal of electrical equipment.

**Input**

Three Spherosyn or Microsyn encoders.

**Resolutions****Spherosyn or Microsyn 10**

(menu selection)  
5µm (0.0002")  
10µm (0.0005")  
20µm (0.001")  
50µm (0.002")

**Microsyn 5**

(menu selection)  
1µm (0.00005")  
2µm (0.0001")  
5µm (0.0002")  
10µm (0.0005")

CE



Certificate No FM36096

**NOTE: NEWALL MEASUREMENT SYSTEMS LTD  
RESERVES THE RIGHT TO CHANGE SPECIFICATIONS WITHOUT NOTICE.**

# CONNECTIONS

- The **C80** is suitable for use only with Newall Spherosyn and Microsyn analogue encoders.
- Ensure that all cables are secured to prevent the connectors from dropping into hazardous positions when unplugged, for example the floor or coolant tray.
- Ensure that all cables are routed to prevent them from being caught on moving parts.
- Turn off the power before connecting the encoder, by disconnecting the power supply connector
- Ensure that the **C80** is grounded to the machine before turning on the machine supply.

## NOTES



DO NOT CONNECT THIS UNIT DIRECTLY TO THE MAINS SUPPLY.



If you have a Newall encoder which is not fitted with D-type connector, an adaptor cable is available. Part No. 307-80980

Contact your supplier for details.




NOTES


# MOUNTING

- The **C80** can be mounted in a variety of ways, depending on the mounting assemblies purchased with the unit:


## Arm Mounting (Non-adjustable)




## Arm Mounting (Adjustable)




## Face Mounting (Adjustable)



### Lathe Mounting (Adjustable) With Arm Assembly



### Lathe Mounting (Adjustable)



## NOTES



During **Setup** and **Special Functions**, the displays may show information other than that described on this page.

See the sections on **Setup** and **Special Functions**, later in this guide.



For more information about the use of the **Navigation Keys** and the **Function Keys**, see the sections on **Setup** and **Special Functions**, later in this guide.



During **Setup** and **Special Functions**, the keys may be used for functions other than those described on this page.

See the sections on **Setup** and **Special Functions**, later in this guide.

**tip**


At the beginning of each working session, set the datum in **Absolute Mode**, then switch the **C80** to **Incremental Mode**.

By using the **C80** in this way, you will be able to return the machine to its absolute datum at any time, simply by switching back to **Absolute Mode**.

## OPERATION

## Understanding the Displays

- The three **Axis** displays normally show the positions of the X,Y and Z axes.
  - The three **Axis Label** displays normally show X,Y and Z, (in Lathe Mode X, Z and Z').
  - While any axis is moving, the **Function** display shows the **Feedrate** of the fastest moving axis, and the **feed** indicator next to the display will illuminate.
- Feedrate** is displayed in mm/sec (to a resolution of 0.5) or inches/min (to a resolution of 1.0).
- The **lathe** and **mill** indicators will be illuminated depending on whether the lathe or mill functions or both, are available.



## Using the Keypad

In normal operation, the keys are used as follows:

- Press to toggle the displays between inches and millimetres.
- Press to toggle the **C80** between **Absolute Mode** and **Incremental Mode**.

**Absolute Mode**

- In this mode, the **C80** will display the positions of the three axes relative to a fixed datum.

**Incremental Mode**

- In this mode, the **C80** can be used to display each position relative to the last position. This is also known as **point-to-point** use.

**Sleep Mode**


- Press to temporarily turn off the displays and the keypad.

While the unit is in **Sleep Mode**, all settings are preserved, but the positions of the three axes are updated. If any of the axes are moved while in **Sleep Mode**, the centre display will show and if any of the keys are touched, the centre display will show .













# STANDARD FUNCTIONS

## Setting the Datum for Each Axis



### Zero

- To zero one display at the current position:  
Press the **Select Key**  for the axis to be zeroed. All readings will now be relative to this new zero point.

### Preset

- To preset one display to a known fixed value:  
Press , then the **Select Key**  for the axis to be preset, then enter the value.  
  
**For Example:** Press         to enter the value . All readings will now be relative to this new value.
- If you make a mistake while entering a number, pressing  will clear the entry one character at a time.



### Recall

- To quickly recall the last preset value for an axis:  
Press , then the **Select Key**  for the axis to be preset. All readings will now be relative to this new value.

## Using Digifind

In the event that a datum is lost, either due to movement following a power failure, or after a fixed point has been entered by mistake, it can easily be re-established, using **Digifind**.








In order to use **Digifind**, the absolute datum for each axis should be marked permanently on the machine.

- Set the axis close to the marked datum - to within:  
6.3mm (0.25") for a Spherosyn encoder or  
2.5mm (0.1") for a Microsyn encoder.
- Switch the **C80** to **Absolute Mode**.
- Press , then the **Select Key**  for the axis to be restored. The display will update to show the exact distance from the datum.

## Using Centerfind

**Centerfind** works by halving the distance displayed on the selected axis. It works in either **Absolute** or **Incremental Mode**.

**For Example:** to find the center of a workpiece that is 100mm wide:

- Set the tool to one edge of the workpiece, and press the **Select Key**  for the axis to be centered. The display shows .
- Set the tool to the other edge of the workpiece. The display shows .
- Press  The display shows '0' in all axes. Press the **Select Key**  for the axis to be centered. The display will now show .
- Move the tool until the display shows . This is the center of the workpiece.

### NOTES



Using **Zero** redefines the datum, so it will not be possible to restore the old datum.

Using **Preset**, **Recall** or **Centerfind** will change the datum - but in **Absolute Mode**, **Digifind** can still be used to return to the old datum.

### tip

Do not move the machine when the **C80's** power is off.

When the power is switched back on again, the **C80** uses **Digifind** automatically to re-establish the datum for each axis.



**Digifind** works only in **Absolute Mode**.

### tip

Set the **C80** to **Incremental** before using **Centerfind**.

By doing this, you will be able to return the machine to its absolute datum afterwards, simply by switching back to **Absolute Mode**.

NOTES

# SETUP

## Using Setup Mode



Normally, **Setup** needs to be done only once, and it is possible that the factory default settings will be suitable and will not require change.

- To enter **Setup Mode**, first exit from any **Special Function** that is running, then press . The centre display shows .
- Press or to cycle up and down the list of options.

The options are listed below, and each is described in detail on the following pages.

Option	Default	Display
Machine Type	Generic	
Encoder Type	all axes: Spherosyn	
Encoder Resolution	all axes: 0.005mm	
Radius / Diameter	all axes: Radius	
Direction	all axes: I	
Error Compensation	all axes: Off	
Linear Compensation	see note 1	
Segmented Compensation	see note 1	
Axis Summing	X and Z' axes	
RS232 Options	None	
Serial Rate	1.0	
Baird Rate	9600	
Parity	None	
Zero Approach On / Off	all axes: Off	
Zero Approach Limit	see note 1	
Taper Display Axis	X axis	
Add Function	see note 2	
Delete Function	see note 2	
Reset		
Store		

- When you have finished setting all the options, select . Press to store any changes made. The middle display shows for a few seconds as your settings are stored. The **C80** exits from **Setup Mode**.
- Alternatively, pressing at any time will exit from **Setup Mode** and abandon any changes.



Not all options will be present, depending on the setting of other options. For example, the **Zero Approach Limit** option will not be present if **Zero Approach** is turned off.



The **Add Function** and **Delete Function** options allow for the download of programmable functions from a PC, connected to the C80 via a serial lead connected to the 15D connection. The serial lead is an option and can be ordered separately, if required. Use Part No. 307-83210. Please contact your supplier for pricing information



## Machine Type

This setting allows you to choose whether the special functions for **Mill** or **Lathe** are available.

There are three possible settings:

- Generic mode  all functions available
- Mill mode  mill functions only
- Lathe mode  lathe functions only

- Press the **Select Key**  next to the  to cycle between the three settings.

## Encoder

### Encoder Type

There are three possible settings for each axis:

- Spherosyn
- Microsyn 10
- Microsyn 5


- Press the **Select Key**  next to the , , or  to cycle between the three settings for each axis.

### Encoder Resolution

The **Resolution** settings available for each axis will depend on the encoder type, and also on the  setting.

	Display		Spherosyn	Microsyn 10	Microsyn 5
	mm	in			
1µm	0.001	0.00005			✓
2µm	0.002	0.0001			✓
5µm	0.005	0.0002	✓	✓	✓
10µm	0.01	0.0005	✓	✓	✓
20µm	0.02	0.001	✓	✓	
50µm	0.05	0.002	✓	✓	

- Press the **Select Key**  next to the , , or  to cycle between the four available settings for each axis.

 The **Encoder** settings must match the actual encoder in use, or the C80 will not display correctly.

NOTES

**tip**

The **Diameter** setting is useful for lathes, and other turning applications to display diameter rather than radius.

**tip**

The **Direction** setting is quite arbitrary. Set it to whichever makes most sense to the machine.

Note, Direction is dependent on where the scale is mounted.



If **Error Compensation** is applied, it is important that it is absolutely correct. If it is not correct, errors could be increased rather than reduced.

**tip**

After setting up the **Error Compensation**, it is advisable to check its effect in normal operation.



**Segmented Compensation** need not be over the entire scale length.

It can be applied just to a length of high importance, or it can be as small as one segment.

See pages 11 and 12 for details on using **Linear and Segmented Error Compensation**

## Radius / Diameter

Selecting the **Diameter** setting causes the **C80** to display double the actual movement on any axis.

There are two possible settings for each axis:

Radius rAd

Diameter d iA

Press the **Select Key** next to the , or to cycle between the two settings for each axis.

## Direction

The **Direction** setting allows you to match the **C80** to the actual direction of travel of any axis.

There are two possible settings for each axis:

d i r. I

d i r. 0

Press the **Select Key** next to the , or to cycle between the two settings for each axis.

## Error Compensation

Errors can result from a number of sources, including machine wear. Where the degree of error increases linearly along the length of travel of the scale, **Linear Error Compensation** should be applied. However, where the errors are local to an area of travel, the **Segmented Error Compensation** should be applied.

There are three possible settings for each axis:

Off Err OFF

Segmented Compensation SEG Err

Linear Compensation Lin Err

Press the **Select Key** next to the , or to cycle between the three settings for each axis.

If one or more axes are set to **Segmented Error Compensation**, or **Linear Error Compensation**, then the next setup option will be to configure the compensation for each of those axes.

- Press .

The middle display changes to Err SET.

### Segmented Error Compensation

In this mode, the scale travel for each axis can be broken down into as many as 99 user-defined segments, with each segment having its own correction factor. The correction factors are calculated by the **C80** by comparison against known, user-supplied standards.

- When power is applied, the display for any axis that is set to use **Segmented Compensation** shows rESET.
- If the machine has not been moved since the power was turned off, simply press , and the **C80** will restore the last positions recorded.
- Alternatively, set each axis close to the **Reference Point** - to within: 6.3mm (0.25") for a Spherosyn encoder or 2.5mm (0.1") for a Microsyn encoder, and press the **Select Key** next to the , or . The **C80** will re-establish alignment with the correction parameters.

### Linear Error Compensation


In this mode, a single constant correction factor for each axis can be applied to all displayed measurements. The correction factor is calculated by the user, and specified in parts per million (ppm). Values between -9999 and +9999 are allowed.

# Segmented Error Compensation

If one or more axes are set to **Segmented Error Compensation**, then the following procedure should be followed to configure the compensation for each of those axes.

## Identification of Correction Parameters

The scale travel is broken down into a number of user-defined segments, each with its own correction factor, measured against a high-accuracy standard. The following parameters need to be identified:



Each **Correction Point** is measured with respect to the **Starting Point - zero** - which is usually set close to one end of the scale. The **Reference Point** can be set anywhere along the scale, and does not need to coincide with either the absolute datum or any of the correction points. However, it may be convenient to make the absolute datum and the reference point the same.

## Setting the Correction Points

As you follow the steps below, it is essential to take the following precaution:

Always approach the **Starting Point**, **Correction Points** and **Reference Point** from the same direction. If you do not, then the size of the tool or probe will render the measurement inaccurate.

- Set one or more axes to **Segmented Compensation** as described on page 10.  
The display should show `Err SET`.
- Press the **Select Key** next to the `X`, `Y` or `Z` to enter the setup procedure for each axis to be configured.  
The display changes to `SET ZERO`.
- 1 Set the machine to the point you have chosen to be the **Starting Point**, and zero the high-accuracy standard at this point. Press `ent`.
- 2 The display changes to `Go to 1`.  
Set the machine to the point you have chosen to be **Correction Point 1**. Press `ent`.
- 3 The display changes to `Ent5d 1`.  
Enter the distance from the **Starting Point**, as measured by the standard.  
**For Example:** Press `6 7 8 . 9 ent` to enter a **Correction Point** of 678.9.  
The C80 will calculate and display the correction factor for this point.
- Press to go to the next point.  
Repeat steps 2 and 3 for each **Correction Point**.  
When all correction points have been entered, press `abs inc`.
- 4 The display changes to `Go to rEF`.  
Set the machine to the point you have chosen as the **Reference Point**. Press `ent`.
- 5 The display returns to `Err SET`.  
If required, press the **Select Key** next to `X`, `Y` or `Z` to enter the setup procedure for another axis.

## NOTES

- Up to 99 segments can be defined per axis.
- To take advantage of **Segmented Error Compensation**, you will need access to a high accuracy standard, such as a laser measuring system.
- **Error Compensation** initially defaults to **Off**, with no points set.  
If **Error Compensation** is set to **Off** after **Correction Points** have been set, the data is retained, but not applied. When **Segmented Error Compensation** is set to **On** again, the data will be re-applied.

➤ This procedure must be carried out in strict sequence, and in full, to be valid. There must be no reversals in direction.

*tip*  
Pressing **Select Key** at steps 1, 2 or 3, will display the current uncorrected position relative to the (Starting Point).


*tip*  
Do not worry about the direction of the standard measurement. For example, 678.9 and -678.9 are treated the same.

*tip*  
Pressing `ce` will clear an entry one character at a time.  
After an entry has been completed by pressing `ent`, pressing `ce` will take you back one step at a time.

NOTES

# Linear Error Compensation

A single constant correction factor for each axis is applied to all displayed measurements.




If one or more axes are set to **Linear Error Compensation**, then the following procedure should be followed to configure the compensation for each of those axes.

## Calculating the Correction Factor

As you follow the steps below, it is essential to take the following precaution:

**Either:** Use a stepped standard, and approach each edge from the same direction.

**Or:** If you must approach each edge from opposite directions, then subtract the width of the tool or measuring probe from the value displayed on the **C80**.



➔ The **Correction Factor** cannot be established while in **Setup Mode**.

Carry out the measurements in **Normal Operating Mode**, then enter **Setup Mode** to set the **Correction Factor**.

➔ Only values between -9999 and 9999 are allowed.

**tip**  
If you make a mistake while entering a number, pressing **ce** will clear the entry one character at a time.

**For Example:** To check the scale against a standard which is exactly 500mm wide:

- Set the tool or probe to one edge of the standard, and press the **Select Key** for the axis to be corrected.

The display shows 0000.

- Set the tool or probe to the other edge of the standard.

The display shows 499800.

- Calculate the correction factor:

$$\text{error} = 500.000 - 499.8 = 0.2\text{mm}$$

$$\text{Correction Factor} = \frac{\text{error}}{\text{standard}} = \frac{0.2}{500} \times 1,000,000 = +400 \text{ ppm (parts per million)}$$

This value displayed on the C80 needs to be increased to match the standard, so this is a positive correction factor. If the display had shown 500.2 for the same standard, the correction factor would be negative -400 ppm.

## Setting the Correction Factor

- Set one or more axes to **Linear Error Compensation** as described on page 10

The display should show Err SET.

- Press the **Select Key** next to the **X**, **Y** or **Z** to enter the setup procedure for each axis to be configured.

The display shows [C] 0, or a previously entered value.

- **For Example:** Press 4 0 0 ± **ent** to enter a **Correction Factor** of -400 ppm.

- Press **ent** again.

The display returns to Err SET.

If required, press the **Select Key** next to the **X**, **Y** or **Z** to enter the setup procedure for another axis.

## RS232 Options

### NOTES

The C80 DRO has the ability to offer basic RS232 communications via a dedicated hardware RS232 compatible port. This is designed for programming of the unit during manufacture, CSS communications and diagnostic purposes. It also fulfils the requirement to log positional data for quality purposes.



RS232 was added as a standard feature to the C80 in March 2005.

- The RS232 configuration settings can be found sandwiched between the **Axis Summing** and **Zero Approach** settings in the set-up structure
- The baud rates for communications are selectable from Set-up. The available baud rates are: 300, 1200, 2400, 4800, 9600, 14400, 19200, 38400
- From the Set-up structure one of three RS232 modes are selectable. These are:


### No RS232

- All RS232 functions are disabled and no outputs are made
- This is the default condition

### Continuous Output


- From the menu structure the frequency of output is to be defined. The options of frequency are: 0.1 - 60.0 in steps of 0.1 second.

### Keyed Output

- When this option is selected, the axes data is transmitted when the  key is pressed, without proceeding keys having been pressed. Thus this option does not require the use of a function key

### Output Data Format

- The current axis data for the axes available on the system are to be transmitted
- For two axis systems, only two axes of data will be transmitted
- The data packet structure of 12 characters is defined as follows:



- The Axis ID is the character shown in the axis I5-segment display at the time of printing. The exception is that for three-axis Lathe applications a lower case 'z' is used to denote the compound Z'=axis. An upper case 'Z' is used to denote the standard Z-axis.

**NOTES**

Continued

**System Settings**

---

Baud rate	=	Configurable (300, 1200, 2400, 4800, 9600, 14400, 19200, 38400)
Data bits	=	8
Parity bit	=	Configurable (Even, Off, None)
Stop bits	=	1
Flow control	=	None


**Default System Settings**

---

Serial option	=	None
Serial rate	=	1.0 (i.e. once per second)
Baud rate	=	9600
Parity bit	=	None

**Connections**

RS232 connection to the unit is made via a 15-pin D-type connector at the rear of the display.



**RS232 Operation**

The RS232 output is configured from the Setup Menu, where four settings are to be found.

- The first is labelled **SERIAL** and refers to the mode of operation, either **CONSTANT**, **SINGLE** or **NONE**. The options are cycled by pressing either the left or right keys on the directional pad.
- The second setting concerns the rate at which RS232 data is generated when in constant mode. It is labelled **SER RATE** and shows a value (in seconds) in the second axis window. Pressing the arrow button next to the value allows the serial rate to be changed. Values in the range 0.1-60.0 can be selected in 0.1s increments (see Note).
- The third setting relates to the baud rate of the RS232 communications. The first axis window is labelled **BAUD RATE** and the second shows the current value. You can select **300**, **1200**, **2400**, **4800**, **9600**, **14400**, **19200** and **38400** by pressing either the left or the right keys on the directional pad.
- The final setting is the parity mode of the RS232 communications. The first axis window shows **PARITY** and the second shows the current setting - either **EVEN**, **ODD** or **NONE**. You can scroll through the options by pressing either the left or right key on the directional pad.

➔ The maximum serial rate is limited by the baud rate, i.e., for a baud rate of 9600 the maximum output serial rate is 0.5s.

Baud Rate	Maximum Serial Rate (s)
300	2.0
1200	1.0
2400	1.0
4800	1.0
9600	0.5
14400	0.5
19200	0.5
38400	0.5

## Axis Summing

NOTES

This setting works in conjunction with the **Summing** function.

- Two of the axis displays show **Add it on**.  
Press the **Select Keys**  or  to cycle between the two settings **X,Z** or **Z,Z'**.

## Zero Approach

This setting provides a visual indication that one or more axes are approaching zero, by flashing the **Axis Label** display.

**For Example:** If **Zero Approach** is turned on for the X axis, with a **Zero Approach Limit** of 1.25, then the axis label display will flash for values

from  to 

- When the axis is within:  
0.05mm (0.002") for a Spherosyn encoder or  
0.025mm (0.001") for a Microsyn encoder


the display will stop flashing.

### Zero Approach On / Off

There are two possible settings for each axis:
















Zero Approach On 

Zero Approach Off 

Press the **Select Key**  next to the ,  or  to cycle between the two settings for each axis.

### Zero Approach Limit

This setting allows you to choose how close to zero the axis needs to be for the display to flash.

- Press  after setting **Zero Approach On / Off**.  
The displays for the selected axes change to  or a previously entered value.
- Press the **Select Key**  next to the ,  or  to choose which axis to edit.
- For Example:** Press      to enter a limit of 1.25.
- If required, press the **Select Key**  next to the ,  or  to enter the limit for another axis.

## Taper Display Axis

This setting works in conjunction with the **Taper** function.

- One of the axis displays shows **TAPER On**  
and the other two displays show **TAPER OFF**.  
Press the **Select Keys**  or  to choose which axis will display the **Taper** function.

## NOTES



THE SERIAL PROGRAMMING LEAD IS SPECIFICALLY DESIGNED FOR CONNECTION TO C-SERIES DIGITAL READOUTS. INCORRECT CONNECTION MAY CAUSE FAILURE.



USE RESET WITH CAUTION. ALL STORED SETTINGS WILL BE LOST IF THIS FUNCTION IS USED.



ALL RESTORE SETTINGS ARE SAVED IMMEDIATELY.



Reset will take approximately 15 seconds.

## Add / Delete Function


These two options allow you to download programmable functions from a PC connected to the **C80** via a serial lead connected to the 15D connection. This serial lead is an option and can be ordered separately if required. Use Part No. 307-83210. Please contact your supplier for pricing information.

New functions are available as Internet downloads and can be found on the Newall Website: [www.newall.com](http://www.newall.com)

## Reset

*This will restore all settings to their factory defaults, and should, therefore, be used only if absolutely necessary.*


The middle display shows rESEt

- Press ent or the **Select Key**  next to the f to select the **Reset** function.
  - While all the stored settings are being erased, the top display shows CLEAR InD, and the middle display shows 0, 00 etc.
  - When **Reset** has finished the middle display returns to rESEt
- The **C80** remains in **Setup Mode**.

## Store

*This will store all settings and exit to Normal Operating Mode.*

The middle display shows StOrE

- Press ent or the **Select Key**  next to the S to select the **Store** function.
- The middle display shows StOrEd for a few seconds, as your settings are stored.  
The **C80** exits from **Setup Mode**.
- Alternatively, pressing setup at any time will exit from **Setup Mode** and abandon any changes.



# SPECIAL FUNCTIONS

In addition to the **Standard Functions** described on Page 7, the **C80** has a number of inbuilt **Special Functions**, that are accessible using the **F1**, **F2** and **F2'** keys.

- Most **Special Functions** are designed to work specifically with **Mill** or **Lathe**, while **Generic** functions are designed to work with either.
- Most **Special Functions** require only one function key for operation, and can be allocated to either **F1** or **F2**.
- The functions marked **F2** require two function keys and can be allocated only to **F2** and **F2'**.

The generic option also includes all Mill and Lathe Special Functions.

## Mill Functions

Special Function	Display
Bolt Hole Circle	BOLT HOL
Arc	ARC
Line Hole	LINE
Polar Coordinates	POLAR

## Lathe Functions

Tool Offsets	TOOL	F2
Taper	TAPER	
Summing	SUMM	
Vector	VECTOR	


## Generic Functions

Sub Datum and Job Numbers	SDNN	F2
---------------------------	------	----

## The Menu Function

Only two **Special Functions** are available for use at any one time.

To find out which function is allocated to each key:

- Press **menu** to see the **Menu**.  
The display shows, 
- Press **menu** again to turn the **Menu** off.

### To use a function


- Press **F1**, **F2** or **F2'**, according to the instructions given later in this guide.

### To allocate a function to a key:

- Press **menu**.
- Press the **Select Key** next to the **1** or **2** to choose which function key to edit.
- Press **▲** or **▼** to cycle up and down the list of **Special Functions**.
- Press **ent** to allocate the selected **Special Function** to the function key.

## NOTES

Each of the **Special Functions** listed here is described in detail later in this guide.

If certain functions are running when you press **menu**, then in place of the function name, the display will show .

If you want to allocate a function, press **menu** again to turn the **Menu** off, if you want to allocate a different function to that function key, then turn the function off before trying again.

## NOTES



This function is also known as **Pitch Circle Diameter (PCD)**.

**tip**

If you make a mistake while entering a number, pressing **ce** will clear the entry one character at a time.

After an entry has been completed by pressing **ent**, pressing the **navigation keys** and will take you backwards and forwards one step at a time.

To turn the function off, finish making any entry, then press the function key again


# MILL FUNCTIONS

Mill functions are available when the **C80 Setup** has been configured for either Mill or Generic operation

## Bolt Hole Circle

This function will calculate the locations of the holes, given the following parameters:

- 1 Plane (**X,Y X,Z** or **Y,Z**)
- 2 Circle Center location
- 3 Circle Diameter
- 4 Number of Holes (up to 99)
- 5 Starting Angle (measured anti-clockwise from 3 o'clock)



### To Set the Function Parameters:

- Press **F1** or **F2** to turn the function on.  
(For three axis units only)
- The function display shows **P**, and the axis displays show in which **Plane** the holes are to be machined.  
Press or to cycle between the three settings **X,Y X,Z** or **Y,Z**.  
Press to move to the next step.
- The function display shows **C**, and the axis displays show the coordinates of the **Circle Center**.  
Press the **Select Key** next to the **X**, **Y** or **Z**, to edit each value as required.  
**For Example:** Press **Y** **9** **9** **.** **7** **ent**.  
Press to move to the next step.

## Bolt Hole Circle Continued

- The function display shows  $\varnothing$ , and the top axis display shows the **Circle Diameter**.

Enter a new value if required.

**For Example:** Press  $\boxed{1}$   $\boxed{5}$   $\boxed{0}$   $\boxed{\text{ent}}$ .

Press  $\blacktriangleright$  to move to the next step.

- The function display shows  $\varnothing$ , and the top display shows the **Number of Holes**.

Enter a new value if required.

**For Example:** Press  $\boxed{5}$   $\boxed{\text{ent}}$ .

Press  $\blacktriangleright$  to move to the next step.

- The function display shows  $\varnothing$ , and the top display shows the **Starting Angle**.

Enter a new value if required.

**For Example:** Press  $\boxed{1}$   $\boxed{8}$   $\boxed{\text{ent}}$ .

Press  $\blacktriangleright$  to finish setting the parameters.

- The function display shows  $\boxed{01}$ .



The axis that is **not** involved in the **Bolt Hole Circle** function will read as normal.

### To Machine the Holes:

The two axis displays for the selected plane now show the distance to the first hole.

- To position the tool ready for machining the hole, move the axes until both displays show zero.

The **function display** shows the number of the hole to be machined.

- Press the **navigation keys**  $\blacktriangleleft$  or  $\blacktriangleright$  to move between the holes, or enter the hole number.

**For Example:** Press  $\boxed{4}$   $\boxed{\text{ent}}$  to move directly to hole 4.

- When all holes have been machined, press  $\boxed{\text{F1}}$  or  $\boxed{\text{F2}}$  to turn the function off.


## NOTES

## Arc Contouring

This function will calculate the locations of the points along the line of the arc, given the following parameters:

- 1 Plane (X,Y X,Z or Y,Z)
- 2 Arc Center location
- 3 Arc Radius
- 4 Starting Point
- 5 Ending Point
- 7 Tool Diameter
- 8 Internal or External Cut (machined to the inside or the outside of the arc)
- 9 Maximum Cut (the smaller the cut, the more points calculated)

## Example

**tip**

If you make a mistake while entering a number, pressing **ce** will clear the entry one character at a time.

After an entry has been completed by pressing **ent**, pressing the navigation keys **◀** and **▶** will take you backwards and forwards one step at a time.

To turn the function off, finish making any entry, then press the function key again.

**To Set the Function Parameters:**

- Press **F1** or **F2** to turn the function on.  
(For three axis units only)
- The function display shows **P**, and the axis displays show in which **Plane** the holes are to be machined.  
Press **▲** or **▼** to cycle between the three settings X,Y, X,Z or Y,Z.  
Press **▶** to move to the next step.
- The function display shows **C**, and the axis displays show the coordinates of the **Arc Center**.  
Press the **Select Key** **◀** next to the **X**, **Y** or **Z**, to edit each value as required.

**For Example:** Press **Y** **◀** **2** **▪** **3** **6** **ent**.

Press **▶** to move to the next step.

## Arc Contouring continued

- The function display shows **r**, and the top display shows the **Arc Radius**.  
Enter a new value if required.  
**For Example:** Press **2** **.** **7** **ent**.  
Press **▶** to move to the next step.
- The function display shows **St**, and the axis displays show the coordinates of the **Starting Point**.  
Press the **Select Key** **◀** next to the **X**, **Y** or **Z**, to edit each value as required.  
**For Example:** Press **Y** **◀** 4.826 **ent**.  
Press **▶** to move to the next step.
- The function display shows **End**, and the axis displays show the coordinates of the **Ending Point**.  
Press the **Select Key** **◀** next to the **X**, **Y** or **Z**, to edit each value as required.  
**For Example:** Press **Y** **◀** 4.174 **ent**.  
Press **▶** to move to the next step.
- The function display shows **Ed**, and the top display shows the **Tool Diameter**.  
Enter a new value if required.  
**For Example:** Press **.** **5** **ent**.  
Press **▶** to move to the next step.
- The function display shows **IE**, and the top axis display shows whether the cut is to be machined to the internal or the external of the arc. The display shows  
**Internal** **rAd-TOOL**  
or **External** **rAd TOOL**.  
Press **▲** or **▼** to cycle between the two settings.  
Press **▶** to move to the next step.
- The function display shows **Cut**, and the top display shows the **Maximum Cut**.  
Enter a new value if required.  
**For Example:** Press **.** **1** **5** **ent**.  
Press **▶** to finish setting the parameters.
- The function display shows **01**.

**To Machine the Arc:**

The two axis displays for the selected plane now show the distance to the Arc starting point

- To position the tool ready for machining the arc, (starting point) move the axes until both displays read zero.  
The function display shows the number of the hole to be machined.
- Press the **navigation keys** **◀** or **▶** to move between the positions,
- When the Arc machining has been completed, press **F1** or **F2** to turn the function off.

**NOTES**

If you enter a **Starting Point** or **Ending Point** that is inconsistent with the **Centre** and **Radius** settings, then the **Centre** and **Radius** settings will override the inconsistent settings.



The axis that is **not** involved in the **Arc** function will read as normal.



The arc must be machined progressively. It is not possible to jump between points on the arc.

**tip**

Move away from the line of the Arc between points to avoid over cutting.


## NOTES

## Line Hole

This function will calculate the locations of the holes, given the following parameters:

- 1 Plane (X,Y X,Z or Y,Z)
- 2 Starting Point
- 3 Line Length
- 4 Number of Holes (up to 99)
- 5 Line Angle

## Example

**tip**

If you make a mistake while entering a number, pressing **ce** will clear the entry one character at a time.

After an entry has been completed by pressing **ent**, pressing the navigation keys **◀** and **▶** will take you backwards and forwards one step at a time.

To turn the function off, finish making any entry, then press the function key again.


## To Set the Function Parameters:

- Press **F1** or **F2** to turn the function on.  
**(For three axis units only)**
- The function display shows **P**, and the axis displays show in which **Plane** the holes are to be machined.  
Press **▲** or **▼** to cycle between the three settings **X,Y**, **X,Z** or **Y,Z**.  
Press **▶** to move to the next step.
- The function display shows **SE**, and the axis displays show the coordinates of the **Starting Point**.  
Press the **Select Key** **◀** next to the **X**, **Y** or **Z**, to edit each value as required.  
**For Example:** Press **Y** **▶** **2** **0** **0** **ent**.  
Press **▶** to move to the next step.
- The function display shows **LEN**, and the top display shows the **Line Length**.  
Enter a new value if required.  
**For Example:** Press **3** **5** **0** **ent**.  
Press **▶** to move to the next step.


continued


## Line Hole Continued

### NOTES

- The function display shows , and the top display shows the **Number of Holes**.  
Enter a new value if required.

**For Example:** Press  .

Press  to move to the next step.

- The function display shows , and the top display shows the **Line Angle**.  
Enter a new value if required.

**For Example::** Press   .

Press  to finish setting the parameters.







- The function display shows .

### To Machine the Holes:

*The two axis displays for the selected plane now show the distance to the first hole.*

- To position the tool ready for machining the hole, move the axes until both displays read zero.

*The function display shows the number of the hole to be machined.*

- Press the **navigation keys**  or  to move between the holes, or enter the hole number.  
**For Example::** Press   to move directly to hole 4.
- When all holes have been machined, press  or  to turn the function off.



The axis that is **not** involved in the **Line Hole** function will read as normal.

## NOTES


## Polar Coordinates

This function will convert the position of two selected axes into Polar coordinates.



The **C80** normally uses the **Cartesian Coordinate System**, in which the position of a point in any plane is defined by two coordinates (**X,Y** **X,Z** or **Y,Z**).

In the **Polar Coordinate System**, an imaginary line is drawn between the position of the point and the datum. The Polar coordinates displayed are the length of the line (**P**), and its angle, measured anti-clockwise from 3 o'clock.

### Example



### To Use the Function:

- Press **F1** or **F2** to turn the function on.
- The axis label displays for two of the axes shows **P** and **A**.  
Press the **Select Keys**  or  to cycle between the three **Plane** settings **X,Y** **X,Z** or **Y,Z**.  
Press **ent** to accept the setting.



The axis that is **not** involved in the **Polar Coordinates** function will display as normal.




# LATHE FUNCTIONS

Lathe functions are available when the **C80 Setup** has been configured for either Lathe or Generic operation.

## Taper

This function is used for turning or measuring a turned, tapered part.

One of the axes is used to display the **Taper** angle: the angle between the present machine position and the datum, in the X,Z plane.



### To Set the Function Parameters:

The selection of which axis is to display the **Taper** angle is carried out in **Setup Mode**.

- To enter **Setup Mode**, first exit from any **Special Function** that is running, then press **setup**.  
The centre display shows **SET UP**.
- Press **▲** or **▼** to choose **TAPER**.  
Press the **Select Key** **◀** next to the **X**, **Z** or **Z'** to choose which axis shows **TAPER On**.
- Press **▲** or **▼** to choose **STORE**, then press **ent** to store the change.

### To Use the Function:

- Press **F1** or **F2** to turn the function on.
- Touch the tool to one end of the taper.  
Press the **Select Keys** **◀** next to the **X** and **Z**, to set the datum.
- Touch the tool to one end of the taper.
- The axis display marked **T** shows the taper angle.
- Press **F1** or **F2** to turn the function off.

## NOTES



The conventional way to set up a lathe is:

- X** Axis – cross travel
- Z** Axis – longitudinal travel
- Z'** Axis – compound travel.

If the **Machine Type** is set to **Generic**, then the axes will be labelled:

- Axis 1** – X
- Axis 2** – Y
- Axis 3** – Z



It is recommended that you use this function in **Incremental Mode**, as it involves changing the datum.



The axes that are **not** showing the **Taper** angle will display as normal.

## NOTES



The conventional way to set up a lathe is:

**X** Axis – cross travel

**Z** Axis – longitudinal travel

**Z'** Axis – compound travel.

If the **Machine Type** is set to **Generic**, then the axes will be labelled:

**A**xis 1 – X

**A**xis 2 – Y

**A**xis 3 – Z

**tip**


Set the **C80** to **Incremental Mode** before using **Tool Offsets**.

By doing this, you will be able to return the machine to its absolute datum afterwards, simply by switching back to **Absolute Mode**.

## Tool Offsets

This function allows you to program the **C80** with **Tool Offsets** for as many as 99 different tools, to save having to reset the datum every time you change tools.

- This function is designed primarily for use in **Lathe Mode**, but can also be used in **Generic Mode**.  
Offsets can be set only for the first two axes, which on a lathe are the **X** and **Z** axes. In the examples opposite, the X axis is set to the diameter of the part, and the Z axis is zeroed at the face.
- **Tool 1 Offset** is special, in that it is tied to the **Machine Datum**, as explained below.



### Tool Set Mode

This mode is accessed through **F2** and is used to set the offsets for each tool.

- Note that the setting of **Tool 1 Offset** in this mode will affect the **Machine Datum**. Similarly, a change to the **Machine Datum** will change **Tool 1 Offset**.  
It is recommended therefore that the **C80** is set to **Incremental Mode** before using this function.
- Note that the setting of each tool offset in this mode is independent of all the others, so a change to the **Machine Datum** or to **Tool 1 Offset** will not affect the other tool offsets.

### Tool Usage Mode

This mode is accessed through **F2'** and is used once all offsets have been set.

- Note that a change to the **Machine Datum** while in this mode will change **all** the offsets.  
This can be useful if the same set of tools is to be used on parts of varying sizes.

### Tool Mode Off

To turn off **Tool Set Mode**, press **F2**.

To turn off **Tool Usage Mode**, press **F2'**.

## NOTES

**To Set the Tool Offsets:**

- Press **F2** to turn on **Tool Set Mode**
- Press **◀** or **▶** to select Datum Tool (Generally Tool No. 1)

The function display shows the tool number **01**

- 1 Take a skim cut along the outside diameter of the part or touch the tool to the surface of the part (if cylindrical). Move the tool away from the part, taking care not to move the X axis. Measure the diameter of the part using a suitable gauge.

Press the **Select Key** **◀** next to the **X** and enter the diameter of the part as measured.

**For Example:** Press **X** **◀** **2** **0** **.** **5** **ent** to enter 20.5.

- 2 Take a facing cut or touch the end of the part with the tool. Move the tool away from the part, taking care not to move the Z axis.

Press the **Select Key** **◀** next to the **Z** and press **ent** to zero the axis.

The Tool Offsets Datum has now been established.

Press **▶** to move to the next tool.

- 3 Touch the tool to the surface of the part. Move the tool away from the part, taking care not to move the X axis. Measure the diameter of the part using a suitable gauge.

Press the **Select Key** **◀** next to the **X** and enter the diameter of the part as measured

**For Example:** Press **X** **◀** **2** **0** **.** **5** **ent** to enter 20.5.

- 4 Touch the end of the part with the tool. Move the tool away from the part, taking care not to move the Z axis

Press the **Select Key** **◀** next to the **Z** and press **ent** to zero the axis.

Repeat Steps 3 and 4 for each tool to be set.

Press **F2** to turn off **Tool Set Mode**.

**To Use **F2** Tool Offsets:**

- Press **F2** to turn on **Tool Usage Mode**.
- Press **◀** or **▶** to select the tool.

The function display shows the tool number **01**, **02** etc, to **99**.

- Press **F2** to turn off **Tool Usage Mode**.

**To Edit the Tool Offsets for Worn or Replacement Tools:**

- Press **F2** to turn on **Tool Usage Mode**.
- Press **◀** or **▶** to select a known good tool.
- Set the axis datum as described in Steps 1 and 2 above. All offsets are now aligned with the correct **Machine Datum**.
- Press **F2** to turn off **Tool Usage Mode**
- Press **F2** to turn on **Tool Set Mode**.
- Set the offsets for each tool as described in Steps 3 and 4 above.
- Press **F2** to turn off **Tool Set Mode**.

**tip**

If you make a mistake while entering a number, pressing

**ce** will clear the entry one character at a time.

To turn the function off, finish making any entry, then press the function key again .

## NOTES



The conventional way to set up a lathe is:

**X** Axis – cross travel

**Z** Axis – longitudinal travel

**Z'** Axis – compound travel.

If the **Machine Type** is set to **Generic**, then the axes will be labelled:

**A**xis 1 – X

**A**xis 2 – Y

**A**xis 3 – Z




The direction of **Z'** may have to be changed in **Setup** to ensure that the axes sum and not subtract.

## Summing

This function allows the movement of the **Z'** axis to be added to the movement of either the **X** axis or the **Z** axis.

The **Summing** function is useful when the compound is set to align with either of those two axes. If the compound is set at an angle, see the next section on the **Vectoring** function.



### To Set the Function Parameters:

The selection of which axes are to be added together is carried out in **Setup Mode**.

- To enter **Setup Mode**, first exit from any **Special Function** that is running, then press . The centre display shows .
- Press or to choose .
- Press or to choose which axes are to be added: **X+Z'** or **Z+Z'**.
- Press or to choose , then press to store the change.

### To Use the Function:

- Press or to turn the function on.
- For **X + Z'**
  - The X display shows the Sum of the two selected axes and the axis identifier shows .
  - The Z display shows the Z axis as normal.
  - The Z' display shows the Z' axis as normal.
- For **Z + Z'**
  - The X display shows the X as normal.
  - The Z display shows the Sum of the two selected axes and the axis identifier shows .
  - The Z' display shows the Z' axis as normal.


Any of the axes can be zeroed or preset in the usual way. The **Sum** display will be altered to take account of the new value.

- Press or to turn the function off.

## Vectoring

This function allows the movement of the X and Z axes to be combined with the angle of the compound. Vectoring is only available on 3 axis units.

The **Vectoring** function is useful when the compound is set at an angle. If the compound is set to align with either the X or the Z axes, see the previous section on the **Summing** function.



### To Set the Function Parameters:

- Press **F1** or **F2** to turn the function on.
- The **X** display shows **Angle**, and the centre display shows the **Vectoring Angle**.  
Enter a new value if required.

**For Example:** Press **3** **5** **ent**.

### To Use the Function:

- The X display shows the combined X axis movement.  
The Z display shows the combined Z axis movement.  
The Z' display shows the Z' axis as normal.  
Any of the axes can be zeroed or preset in the usual way. The **Vectoring** displays will be altered to take account of the new value.
- Press **F1** or **F2** to turn the function off.

## NOTES



The conventional way to set up a lathe is:

**X** Axis – cross travel

**Z** Axis – longitudinal travel

**Z'** Axis – compound travel.

If the **Machine Type** is set to **Generic**, then the axes will be labelled:

**Axis 1** – X

**Axis 2** – Y

**Axis 3** – Z

### tip

If you make a mistake while entering a number, pressing **ce** will clear the entry one character at a time.

To turn the function off, finish making any entry, then press the function key again.

NOTES



The conventional way to set up a lathe is:

- X Axis – cross travel
- Z Axis – longitudinal travel
- Z' Axis – compound travel.

If the **Machine Type** is set to Mill or **Generic**, then the axes will be labelled:

- Ax1 – X
- Ax2 – Y
- Ax3 – Z



**Absolute Datum vs Sub-Datum**

Note that all **Sub-Datums** are relative to the **Absolute Datum**, so if the **Absolute Datum** is changed, the **Sub-Datums** will change accordingly.

The **Sub-Datum** function always works in **Absolute Mode**. If the C80 is in **Incremental Mode** when the function is turned on, the C80 will switch to **Absolute Mode**.



Other functions may be used in conjunction with Sub-Datums, e.g. Bolt Hole Circle to produce a repeated pattern of holes about different Sub-Datum positions.

# GENERIC FUNCTIONS

In Generic mode all Lathe and Mill functions are also available


## Sub-Datums and Jobs

### Sub-Datum

This function allows as many as 99 machining steps to be stored in **Sub-Datum Memory**.

In operation, the absolute datum of the machine is replaced by each **Sub-Datum** in turn, allowing the operator to work to zero for each step instead of having to constantly refer to a printed list of coordinates.

### Example




### Jobs

This function allows the stored Sub-Datums to be divided into groups so that a number of individual **Jobs** can be identified by the operator.









**Note:** Because of the way in which the Sub-Datum Memory is used:

When **Job** markers are inserted, all the following **Sub-Datum** numbers are incremented to account for the presence of the markers in memory.




### Example





**To Turn the Function On and Off:**

- Press **F2** to turn the function on.  
The display shows 
- Press the **Select Key**  next to the **S**.  
The display changes to 
- Enter the number of the **Sub-Datum** you wish to go to.  
**For Example:** Press **1** **ent** to go to **Sub-Datum 1**.
- The function display shows the **Sub-Datum** number ,  upto 
- Step from one **Sub-Datum** to the next by pressing the **Select Key**  and .
- Press **abs inc** to turn the function off.



**To Set a Sub Datum:**

- Go to the **Sub-Datum** that is to be set, then use either of these two methods:  
**Teach Method;**
  - Move the machine to the position to be stored as the **Sub-Datum**.  
Press **F2**. All displays show 
  - The **Sub-Datum** is now set.
- or
- **Preset Method;**  
You do not need to move the machine.
  - Press **preset**, then the **Select Key**  next to the first axis to be set.
  - Enter the position of the Sub-Datum relative to the absolute datum, then press **F2**.
- For Example:** Press **Y**  **9** **9** **.** **7** **F2** to enter the Sub-Datum position 99.7 into the Y axis.  
The display will show the distance from the current machine position to the **Sub-Datum**.
- Set any other axes that need to be set.

**To Insert a Sub-Datum:**

- Go to the point where the new **Sub-Datum** is to be inserted.
- Press **ins**.  
The display shows 
- Press the **Select Key**  next to the **S**.  
**Note: Pressing any other key will cancel the operation.**  
All the following **Sub-Datum** numbers are incremented by one after a short time delay, and the display shows the current machine position.
- Set the new **Sub-Datum** as described above.


**To Delete a Sub-Datum:**



- Go to the **Sub-Datum** that is to be deleted.
- Press **del**.  
The display shows 
- Press the **Select Key**  next to the **S**.  
**Note: Pressing any other key will cancel the operation.**  
All the following **Sub-Datum** numbers are decremented by one, after a short time delay, and the display shows the next **Sub Datum**.

**NOTES**

*tip*

Once the function is on, you can go from one **Sub-Datum** to another, by either of these two methods:

1  
Press **F2**, then **S**  then enter the number of the **Sub-Datum** you wish to go to.

2  
Press the **Select Keys**  and  to step from one **Sub-Datum** to the next.

*tip*

If you make a mistake while entering a number, pressing **ce** will clear the entry one character at a time.


To turn this function off, finish making any entry, then press **abs inc**.

**NOTES**



**tip**

Once the function is on, you can go from one **Sub-Datum** to another, by either of these two methods:

1

Press **F2**, then **S**  then enter the number of the **Sub-Datum** you wish to go to.

2

Press the **Select Keys**  and  to step from one **Sub-Datum** to the next.

**tip**

If you make a mistake while entering a number, pressing **ce** will clear the entry one character at a time.



To turn this function off, finish making any entry, then press **abs inc**.

**To Insert a Job Marker:**

- Go to the point where the new **Job** marker is to be inserted.
- Press **ins**.


The display shows .  


- Press the **Select Key**  next to the **J**. Pressing any other key will cancel the operation.

The display changes to .  


*For a **Start Job** marker;*

- Press **ent** to confirm.

The display changes to 


- Enter the number of the **Job** you wish to add.

**For Example:** Press **1** **ent** to insert the marker for **Start Job 1**.

All the following **Sub-Datum** numbers are incremented by one, and the display shows the new **Start Job** marker.

*For an **End Job** marker*

- Press  or .

The display changes to 

Press **ent** to confirm.

All the following **Sub-Datum** numbers are incremented by one, and the display shows the new **End Job** marker.

**To Delete a Job Marker:**

- Go to the **Job** marker that is to be deleted.
- Press **del**.

The display show 

- Press the **Select Key**  next to the **S**. Pressing any other key will abandon the operation.


All the following **Sub-Datum** numbers are decremented by one, and the display shows the next **Sub-Datum**.

**To Find a Job:**

- Press **F2**.

The display shows .  



- Press the **Select Key**  next to the **J**.


The display changes to 

- Enter the number of the **Job** you wish to find.

**For Example:** Press **2** **ent** to find **Job 2**.



If you enter an invalid **Job** number, the display will show **Job 1**.

Press  or  to choose a valid job number. Press **ent** to continue.

- The display shows the **Start Job** marker.
- To find the first **Sub-Datum** of the Job, Press .



# TROUBLESHOOTING

Symptom	Solutions
The display is blank.	<ul style="list-style-type: none"> <li>The <b>C80</b> may be in <b>Sleep Mode</b>. Press .</li> <li>Check that the power supply is correctly connected to a working mains outlet.</li> <li>Check that the power supply cables are not damaged.</li> <li>Check that the power supply voltage is 15Vdc <math>\pm</math>10%.</li> <li>Disconnect all encoder cables. A defective encoder can prevent the <b>C80</b> from working.</li> <li>Check power supply lead on rear of C80 display to ensure that it is illuminated</li> </ul>
The display works, but resets from time to time without any keys being pressed.	<ul style="list-style-type: none"> <li>This suggests either that the supply voltage is too low, or that the power supply or mains supply has an intermittent fault.</li> <li>Check that the power supply voltage is 15Vdc <math>\pm</math>10%.</li> <li>Check that all connections are secure.</li> </ul>
The display works, but gives erratic readings, the last digit jitters or the measurements jump to new figures unexpectedly.	<ul style="list-style-type: none"> <li>This suggests that there may be a poor earth (ground) connection.</li> <li>Both the <b>C80</b>, and the machine on which it is installed, must have proper earth (ground) connections. (see page 3)</li> <li>There may be a problem with the encoder (see below).</li> </ul>
 appears in the display.	<ul style="list-style-type: none"> <li>This indicates that the unit is not receiving a proper signal from the encoder.</li> <li>Check that the encoder connections are secure.</li> <li>Check that there is no damage to the connectors or to the encoder.</li> <li>Switch the <b>C80</b> off and back on again.</li> <li>Swap the encoder to another axis to confirm whether the encoder or the <b>C80</b> is at fault (see <b>tip</b>).</li> </ul>
The unit will not respond to any key presses.	<ul style="list-style-type: none"> <li>Disconnect the <b>C80</b> from its power supply, wait 15 seconds and then reconnect.</li> </ul>
Readings are incorrect	<ul style="list-style-type: none"> <li>Check <b>Encoder Type</b> to ensure correct selection.</li> <li>Check the <b>Radius / Diameter</b> setting. The <b>Diameter</b> setting will cause the axis to read double.</li> <li>Check <b>Error Compensation</b> factors.</li> <li>If using <b>Segmented Error Compensation</b>, verify the datum position.</li> <li>Swap the encoder to another axis to confirm whether the encoder or the <b>C80</b> is at fault (see <b>tip</b>).</li> <li>Check that there is no damage to the encoder or its cable.</li> <li>Check that the encoder is fixed firmly and aligned correctly, as described in the Spherosyn / Microsyn Installation manual.</li> <li>Check that there is no binding on the scale. With the scale brackets slightly loosened, you should be able to slide the scale back and forth with minimal resistance.</li> <li>If you have a Spherosyn scale, check that the scale is not bent, by removing it and rolling it on a flat surface.</li> </ul>

If the solutions suggested above do not solve your problem, contact Newall for further instruction.

# CLEANING

- Disconnect the power supply from the **C80** before cleaning.
- Do not use corrosive or abrasive cleaning materials.
- Do not use compressed air.
- Apply a small amount of mild soap to a lint-free cloth. Use this to wipe over the case and keypad, taking care not to allow fluid into the connectors.

## NOTES

### tip

Providing the machine has not been moved more than:  
6.3mm (0.25") for a Spherosyn Encoder or  
2.5mm (0.1") for a Microsyn Encoder

the datum position will not be lost by switching the power off and back on again.

### tip

When swapping encoders to trace a fault:

1

Check that two axes are set to the correct encoder types.

2

Move the encoder from the malfunctioning axis to a working axis.

If the fault stays with the same encoder, then the encoder is at fault. If the fault does not follow with the encoder the C80 is at fault



FOLLOW THESE INSTRUCTIONS CAREFULLY TO AVOID DAMAGE TO THE **C80**.

**HEAD OFFICE**

**Newall Measurement Systems Ltd.**

Technology Gateway, Cornwall Road  
South Wigston

Leicester LE18 4XH

United Kingdom

Telephone: +44 (0)116 264 2730

Facsimile: +44 (0)116 264 2731

Email: [sales@newall.co.uk](mailto:sales@newall.co.uk)

Web: [www.newall.co.uk](http://www.newall.co.uk)

**Newall Electronics, Inc.**

1778 Dividend Drive

Columbus, OH 43228

Telephone: +1 614 771 0213

Toll Free: 800.229.4376

Facsimile: +1 614 771 0219

Email: [sales@newall.com](mailto:sales@newall.com)

Web: [www.newall.com](http://www.newall.com)