

C70

Digital Readout Display



CONTENTS

2	SPECIFICATIONS
3	CONNECTIONS
4	MOUNTING
4	Arm Mounting (Non-adjustable)
4	Arm Mounting (Adjustable)
5	Face Mounting (Adjustable)
5	Lathe Mounting (Adjustable)
6	OPERATION
6	Understanding the Displays
6	Using the Keypad
7	STANDARD FUNCTIONS
7	Setting the Datum for Each Axis
7	Using Digifind
7	Using Centerfind
8	SETUP
8	Using Setup Mode
9	Encoder
10	Radius / Diameter
10	Direction
10	Error Compensation
11	Segmented Error Compensation
12	Linear Error Compensation
13	Zero Approach
14	SPECIAL FUNCTIONS
14	Add / Delete Function
14	Reset
14	Store
15	The Menu Function
16	TROUBLESHOOTING
16	CLEANING
16	NOTES

NOTES

SPECIFICATIONS

Electrical

EMC and Low Voltage Compliance

BS EN 55022:1998 Class B

BS EN 55024:1998

Power Supply Unit (supplied)

100 - 240V (47 - 63Hz)

External switch-mode

Conforms to Low Voltage Directive

EN 60 950:1992/

A1:1993/ A2:1994/ A3:1996/ A4:1997

Physical

Height

265mm (10.43")

Width

180mm (7.09")

Depth (not including connectors)

50mm (1.97")

Weight

2.9kg (6.38lb)

Environmental

Operating Temperature

0 to 45°C

Storage Temperature

-20 to 70°C

Environmental Conditions

Indoor Use, IP20 (IEC 529)

Relative Humidity

Maximum 80% for temperatures up to 31°C
decreasing linearly to 33% at 45°C

Disposal

At the end of its life, the **C70** system should be disposed of in a safe manner applicable to electronic goods.



DO NOT BURN.

The casework is suitable for recycling. If you have any doubt about how to dispose of your unit, please return it to Newall and we will provide this service for you.

Input

Three Spherosyn or Microsyn encoders.

Resolutions

Spherosyn or Microsyn 10

(menu selection)

5µm (0.0002")

10µm (0.0005")

20µm (0.001")

50µm (0.002")

Microsyn 5

(menu selection)

1µm (0.00005")

2µm (0.0001")

5µm (0.0002")

10µm (0.0005")



Certificate No FM36096

**NOTE: NEWALL MEASUREMENT SYSTEMS LTD
RESERVES THE RIGHT TO CHANGE SPECIFICATIONS WITHOUT NOTICE.**

CONNECTIONS

- The C70 is suitable for use only with Newall Spherosyn and Microsyn analogue encoders.
- Ensure that all cables are secured to prevent the connectors from dropping into hazardous positions when unplugged, for example the floor or coolant tray.
- Ensure that all cables are routed to prevent them from being caught on moving parts.
- Turn off the power before connecting the encoder, by disconnecting the power supply connector.
- Ensure that the C70 is grounded to the machine before turning on the machine supply.

NOTES



DO NOT CONNECT THIS UNIT DIRECTLY TO THE MAINS SUPPLY.



→ If you have a Newall encoder which is not fitted with D-type connector, an adaptor cable is available. Part No. 307-80980


Contact your supplier for details.

NOTES


MOUNTING

- The C70 can be mounted in a variety of ways, depending on the mounting assemblies purchased with the unit:


Arm Mounting (Non-adjustable)




Arm Mounting (Adjustable)




Face Mounting (Adjustable)



Lathe Mounting (Adjustable) With Arm Assembly



Lathe Mounting (Adjustable)




NOTES

OPERATION

Understanding the Displays

- The three **Axis** displays normally show the positions of the X, Y and Z axes.
- The three **Axis Label** displays normally show X, Y and Z, (in Lathe Mode X, Z and Z').
- While any axis is moving, the **Function** display shows the **Feedrate** of the fastest moving axis, and the **feed** indicator next to the display will illuminate.
Feedrate is displayed in mm/sec or inches/min, to a resolution on 0.1.
- The **lathe** and **mill** indicators will be illuminated depending on whether the lathe or mill functions or both, are available.



Using the Keypad

In normal operation, the keys are used as follows:

- Press to toggle the displays between inches and millimetres.
- Press to toggle the C70 between absolute mode and incremental mode.

Absolute Mode

- In this mode, the C70 will display the positions of the three axes relative to a fixed datum.

Incremental Mode

- In this mode, the C70 can be used to display each position relative to the last position. This is also known as **point-to-point** use.

Sleep Mode

- Press to temporarily turn off the displays and the keypad.

While the unit is in **Sleep Mode**, all settings are preserved, but the positions of the three axes are updated. If any of the axes are moved while in **Sleep Mode**, the centre display will show **d ISPLACd**, and if any of the keys are touched, the centre display will show **TouchEd**.

tip

At the beginning of each working session, set the datum in **Absolute Mode**, then switch the C70 to **Incremental Mode**.

By using the C70 in this way, you will be able to return the machine to its absolute datum at any time, simply by switching back to **Absolute Mode**.


STANDARD FUNCTIONS

NOTES

Setting the Datum for Each Axis


Zero



- To zero one display at the current position:

Press the **Select Key**  for the axis to be zeroed. All readings will now be relative to this new zero point.

Preset

- To preset one display to a known fixed value:


Press **preset**, then the **Select Key**  for the axis to be preset, then enter the value.

For Example: Press **preset**  **±** **1** **9** **.** **6** **ent** to enter the value . All readings will now be relative to this new value.

- If you make a mistake while entering a number, pressing **ce** will clear the entry one character at a time.

Recall

- To quickly recall the last preset value for an axis:

Press **recall**, then the **Select Key**  for the axis to be preset. All readings will now be relative to this new value.



Using **Zero** redefines the datum, so it will not be possible to restore the old datum.

Using **Preset**, **Recall** or **Centerfind** will change the datum - but in Absolute Mode, **Digifind** can still be used to return to the old datum.

tip


Do not move the machine when the C70's power is off.

When the power is switched back on again, the C70 uses **Digifind** automatically to re-establish the datum for each axis.

Using Digifind

In the event that a datum is lost, either due to movement following a power failure, or after a fixed point has been entered by mistake, it can easily be re-established, using **Digifind**.

In order to use **Digifind**, the absolute datum for each axis should be marked permanently on the machine.

- Set the axis close to the marked datum - to within:
6.3mm (0.25") for a Spherosyn encoder or
2.5mm (0.1") for a Microsyn encoder.
- Switch the C70 to **Absolute** mode.
- Press **ref**, then the **Select Key**  for the axis to be restored. The display will update to show the exact distance from the datum.








Digifind works only in Absolute Mode.

Using Centerfind

Centerfind works by halving the distance displayed on the selected axis. It works in either **Absolute** or **Incremental Mode**.

For Example: to find the center of a workpiece that is 100mm wide:

- Set the tool to one edge of the workpiece, and press the **Select Key**  for the axis to be centered. The display shows .
- Set the tool to the other edge of the workpiece. The display shows .
- Press **1/2**. The display shows .
- Move the tool until the display shows . This is the center of the workpiece.

tip

Set the C70 to incremental before using **Centerfind**.

By doing this, you will be able to return the machine to its absolute datum afterwards, simply by switching back to **Absolute Mode**.

NOTES





SETUP

Using Setup Mode











➤
Normally, **Setup** needs to be done only once, and it is possible that the factory default settings will be suitable and will not require change.





➤ 1
Not all options will be present, depending on the setting of other options.
For example, the **Zero Approach Limit** option will not be present if **Zero Approach** is turned off.

➤ 2
The **Add Function** and **Delete Function** options allow for the download of programmable functions from a PC, connected to the C70 via a serial lead connected to Axis 1. The serial lead is an option and can be ordered separately, if required using Part No. 307-80990. Please contact Newall for pricing information

- To enter **Setup Mode**, first exit from any **Special Function** that is running, then press .
The centre display shows .
- Press  or  to cycle up and down the list of options.

The options are listed below, and each is described in detail on the following pages.




Option	Default	Display
Encoder Type	all axes: Spherosyn	
Encoder Resolution	all axes: 0.005mm	
Radius / Diameter	all axes: Radius	
Direction	all axes: 1	
Error Compensation	all axes: Off	
Linear Compensation	see note 1	
Segmented Compensation	see note 1	
Zero Approach On / Off	all axes: Off	
Zero Approach Limit	see note 1	
Add Function	see note 2	
Delete Function	see note 2	
Reset		
Store		

- When you have finished setting all the options, select .
Press  to store any changes made.
The middle display shows  for a few seconds, as your settings are stored.
The **C70** exits from **Setup Mode**.
- Alternatively, pressing  at any time will exit from **Setup Mode** and abandon any changes.

Encoder


Encoder Type

There are three possible settings for each axis:





Spherosyn	
Microsyn 10	
Microsyn 5	


- Press the **Select Key**  next to the ,  or  to cycle between the three settings for each axis.

Encoder Resolution

The **Resolution** settings available for each axis will depend on the encoder type, and also on the  setting.

	Display		Spherosyn	Microsyn 10	Microsyn 5
	mm	in			
1µm	0.001	0.00005	✓
2µm	0.002	0.0001	✓
5µm	0.005	0.0002✓✓	✓
10µm	0.01	0.0005✓✓	✓
20µm	0.02	0.001✓✓	
50µm	0.05	0.002✓✓	

- Press the **Select Key**  next to the ,  or  to cycle between the four available settings for each axis.

 The **Encoder** settings must match the actual encoder in use, or the C70 will not display correctly.

NOTES

tip

The **Diameter** setting is useful for lathes, and other turning applications, to display diameter rather than radius.

tip

The **Direction** setting is quite arbitrary. Set it to whichever makes most sense to the machine.

NB, Direction is dependent on where the scale is mounted



If **Error Compensation** is applied, it is important that is absolutely correct. If it is not correct, errors could be increased rather than reduced.

tip

After setting up the **Error Compensation**, it is advisable to check its effect in normal operation.



Segmented Compensation need not be over the entire scale length.

It can be applied just to a length of high importance, or it can be as small as one segment.

Radius / Diameter

Selecting the **Diameter** setting causes the C70 to display double the actual movement on any axis.

There are two possible settings for each axis:

Radius rAd

Diameter dIA

- Press the **Select Key** next to the **X**, **Y** or **Z** to cycle between the two settings for each axis.

Direction

The **Direction** setting allows you to match the C70 to the actual direction of travel of any axis.

There are two possible settings for each axis:

dir. I

dir. 0

- Press the **Select Key** next to the **X**, **Y** or **Z** to cycle between the two settings for each axis.

Error Compensation

Errors can result from a number of sources, including machine wear. Where the degree of error increases linearly along the length of travel of the scale, Linear Error Compensation should be applied. However, where the errors are local to an area of travel, the Segmented Error Compensation should be applied.

There are three possible settings for each axis:

Off Err OFF

Segmented Compensation SEG Err

Linear Compensation Lin Err

See pages 11 and 12 for details on using Linear and Segmented Error Compensation

- Press the **Select Key** next to the **X**, **Y** or **Z** to cycle between the three settings for each axis.

If one or more axes are set to **Segmented Error Compensation**, or **Linear Error Compensation**, then the next setup option will be to configure the compensation for each of those axes.

- Press .
The middle display changes to Err SET.

Segmented Error Compensation

In this mode, the scale travel for each axis can be broken down into as many as 99 user-defined segments, with each segment having its own correction factor. The correction factors are calculated by the C70 by comparison against known, user-supplied standards.

- When power is applied, the display for any axis that is set to use **Segmented Compensation** shows rESET.
- If the machine has not been moved since the power was turned off, simply press , and the C70 will restore the last positions recorded.
- Alternatively, set each axis close to the **Reference Point** - to within:
6.3mm (0.25") for a Spherosyn encoder or
2.5mm (0.1") for a Microsyn encoder,
and press the **Select Key** next to the **X**, **Y** or **Z**. The C70 will re-establish alignment with the correction parameters.

Linear Error Compensation


In this mode, a single constant correction factor for each axis can be applied to all displayed measurements. The correction factor is calculated by the user, and specified in parts per million (ppm). Values between -9999 and +9999 are allowed.

Segmented Error Compensation

If one or more axes are set to **Segmented Error Compensation**, then the following procedure should be followed to configure the compensation for each of those axes.

Identification of Correction Parameters

The scale travel is broken down into a number of user-defined segments, each with its own correction factor, measured against a high-accuracy standard. The following parameters need to be identified:







Each **Correction Point** is measured with respect to the **Starting Point - zero** - which is usually set close to one end of the scale. The **Reference Point** can be set anywhere along the scale, and does not need to coincide with either the absolute datum or any of the correction points. However, it may be convenient to make the absolute datum and the reference point the same.

Setting the Correction Points

As you follow the steps below, it is essential to take the following precaution:


Always approach the **Starting Point**, **Correction Points** and **Reference Point** from the same direction. If you do not, then the size of the tool or probe will render the measurement inaccurate.

- Set one or more axes to **Segmented Compensation** as described on page 10.
The display should show, `Err SET`.
- Press the **Select Key**  next to the `X`, `Y` or `Z` to enter the setup procedure for each axis to be configured.
The display changes to `SET 2ErD`.
- 1 Set the machine to the point you have chosen to be the **Starting Point**, and zero the high-accuracy standard at this point. Press `ent`.
- 2 The display changes to `Go to 1`.
Set the machine to the point you have chosen to be **Correction Point 1**. Press `ent`.
- 3 The display changes to `Entsd 1`.
Enter the distance from the **Starting Point**, as measured by the standard.
For Example: Press `6` `7` `8` `.` `9` `ent` to enter a Correction Point of 678.9.
The C70 will calculate and display the correction factor for this point.
- Press  to go to the next point.
Repeat steps 2 and 3 for each Correction Point.
When all correction points have been entered, press .
- 4 The display changes to `Go to REF`.
Set the machine to the point you have chosen as the **Reference Point**. Press `ent`.
- 5 The display returns to `Err SET`.
If required, press the **Select Key**  next to `X`, `Y` or `Z` to enter the setup procedure for another axis.

NOTES

- ➔ Up to 99 segments can be defined per axis
- ➔ To take advantage of **Segmented Error Compensation**, you will need access to a high accuracy standard, such as a laser measuring system.
- ➔ **Error Compensation** initially defaults to **off**, with no points set.
If **Error Compensation** is set to **Off** after Correction Points have been set, the data is retained, but not applied. When **Segmented Error Compensation** is set to **On** again, the data will be re-applied.

➔ This procedure must be carried out in strict sequence, and in full, to be valid. There must be no reversals in direction.

tip
Pressing select key  at steps 1, 2 or 3, will display the current uncorrected position relative to the (Starting Point).


tip
Do not worry about the direction of the standard measurement. eg. 678.9 and -678.9 are treated the same.

tip
Pressing `ce` will clear an entry one character at a time.
After an entry has been completed by pressing `ent`, pressing `ce` will take you back one step at a time.

NOTES

Linear Error Compensation

A single constant correction factor for each axis is applied to all displayed measurements.




If one or more axes are set to **Linear Error Compensation**, then the following procedure should be followed to configure the compensation for each of those axes.

Calculating the Correction Factor

As you follow the steps below, it is essential to take the following precaution:

- Either:** Use a stepped standard, and approach each edge from the same direction.
- Or:** If you must approach each edge from opposite directions, then subtract the width of the tool or measuring probe from the value displayed on the C70.



For Example: To check the scale against a standard which is exactly 500mm wide:

- Set the tool or probe to one edge of the standard, and press the **Select Key** for the axis to be corrected.
The display shows 0000.
- Set the tool or probe to the other edge of the standard.
The display shows 499800.
- Calculate the correction factor:
error = 500.000 - 499.8 = 0.2mm
Correction Factor = $\frac{\text{error}}{\text{standard}} = \frac{0.2}{500} \times 1,000,000 = +400$ ppm (parts per million)

This value displayed on the C80 needs to be increased to match the standard, so this is a positive correction factor. If the display had shown 500.2 for the same standard, the correction factor would be negative -400 ppm.

Setting the Correction Factor

- Set one or more axes to **Linear Error Compensation** as described on page 10
The display should show, Err SET.
 - Press the **Select Key** next to the X, Y or Z to enter the setup procedure for each axis to be configured.
The display shows LC 0, or a previously entered value.
 - **For Example:** Press 4 0 0 ± ent to enter a **Correction Factor** of -400 ppm.
 - Press ent again.
The display returns to Err SET.
- If required, press the **Select Key** next to the X, Y or Z to enter the setup procedure for another axis.

➔ The **Correction Factor** cannot be established while in **Setup Mode**. Carry out the measurements in **Normal Operating Mode**, then enter **Setup Mode** to set the **Correction Factor**.

➔ Only values between -9999 and 9999 are allowed.

tip
If you make a mistake while entering a number, pressing ce will clear the entry one character at a time.

Zero Approach

This setting provides a visual indication that one or more axes are approaching zero, by flashing the **Axis Label** display.

For Example: If **Zero Approach** is turned on for the X axis, with a **Zero Approach Limit** of 1.25, then the axis label display will flash for values

from to


- When the axis is within:
0.05mm (0.002") for a Spherosyn encoder or
0.025mm (0.001") for a Microsyn encoder
the display will stop flashing.

Zero Approach On / Off

There are two possible settings for each axis:




Zero Approach On

Zero Approach Off

- Press the **Select Key**  next to the , or to cycle between the two settings for each axis.

Zero Approach Limit

This setting allows you to choose how close to zero the axis needs to be for the display to flash.

- Press  after setting **Zero Approach On / Off**.
The displays for the selected axes change to or a previously entered value.
- Press the **Select Key**  next to the , or to choose which axis to edit.
- For Example:** Press to enter a limit of 1.25.
- If required, press the **Select Key**  next to the , or to enter the limit for another axis.

NOTES



THE SERIAL PROGRAMMING LEAD IS SPECIFICALLY DESIGNED FOR CONNECTION TO C-SERIES DIGITAL READOUTS. INCORRECT CONNECTION MAY CAUSE FAILURE.



USE RESET WITH CAUTION.

ALL STORED SETTINGS WILL BE LOST IF THIS FUNCTION IS USED



ALL RESTORE CHANGES ARE SAVED IMMEDIATELY



Reset will take approximately 15 seconds

Add / Delete Function

These two options allow you to download programmable functions from a PC connected to the C70 via a serial lead connected to axis 1. This serial lead is an option and can be ordered separately if require using Part No. 307-80990. Please contact Newall for pricing information.

New functions are available as Internet downloads and can be found on the Newall Website: www.newall.com

Reset

This will restore all settings to their factory defaults, and should, therefore, be used only if absolutely necessary.

The middle display shows:

- Press or the **select key** next to the to select the **Reset** function.
- While all the stored settings are being erased, the top display shows: and the middle display shows , etc.
- When **Reset** has finished the middle display returns to:

The **C80** remains in **Setup Mode**.

Store

This will store all settings and exit to Normal Operating Mode.


The middle display shows

- Press or the **select key** next to the to select the **Store** function.
- The middle display shows for a few seconds, as your settings are stored.
The **C70** exits from **Setup Mode**.
- Alternatively, pressing at any time will exit from **Setup Mode** and abandon any changes.

The Menu Function


Only two **Special Functions** are available for use at any one time.

To find out which function is allocated to each key:




- Press  to see the **Menu**.

The display shows,







CLEAR 1
CLEAR 2

- Press  again to turn the **Menu** off.

To use a function:



- Press ,  or , according to the instructions given later in this guide.


To allocate a function to a key:

- Press .
- Press the **Select Key** next to the  or  to choose which function key to edit.
- Press  or  to cycle up and down the list of **Special Functions**.
- Press  to allocate the selected **Special Function** to the function key.

Note: The C70 has no special functions programmed as standard. Please see the Newall Website: www.newall.com to see what new features may be available






If certain functions are running when you press , then in place of the function name, the display will show .

Press  again to turn the **Menu** off, if you want to allocate a different function to that function key, then turn the function off before trying again.

TROUBLESHOOTING

NOTES

Symptom	Solutions
The display is blank.	<ul style="list-style-type: none"> The C70 may be in Sleep Mode. Press . Check that the power supply is correctly connected to a working mains outlet. Check that the power supply cables are not damaged. Check that the power supply voltage is 19Vdc \pm10%. Disconnect all encoder cables. A defective encoder can prevent the C70 from working. Check power supply lead on rear of C70 display to ensure that it is illuminated.
The display works, but resets from time to time without any keys being pressed.	<ul style="list-style-type: none"> This suggests either that the supply voltage is too low, or that the power supply or mains supply has an intermittent fault. Check that the power supply voltage is 19Vdc \pm10%. Check that all connections are sound.
The display works, but gives erratic readings, the last digit jitters or the measurements jump to new figures unexpectedly.	<ul style="list-style-type: none"> This suggests that there may be a poor earth (ground) connection. Both the C70, and the machine on which it is installed, must have proper earth (ground) connections. (see page 3) There may be a problem with the encoder (see below).
 or  appears in the display.	<ul style="list-style-type: none"> This indicates that the unit is not receiving a proper signal from the encoder. Check that the encoder connections are sound. Check that there is no damage to the connectors or to the encoder. Switch the C70 off and back on again. Swap the encoder to another axis to confirm whether the encoder or the C70 is at fault (see tip).
The unit will not respond to any key presses.	<ul style="list-style-type: none"> Disconnect the C70 from its power supply, wait 15 seconds and then reconnect.
Readings are incorrect	<ul style="list-style-type: none"> Check Encoder Type to ensure correct selection. Check the Radius / Diameter setting. The Diameter setting will cause the axis to read double. Check Error Compensation factors. If using Segmented Error Compensation, verify the datum position. Swap the encoder to another axis to confirm whether the encoder or the C70 is at fault (see tip). Check that there is no damage to the encoder or its cable. Check that the encoder is fixed firmly and aligned correctly, as described in the Spherosyn / Microsyn Installation manual. Check that there is no binding on the scale. With the scale brackets slightly loosened, you should be able to slide the scale back and forth with minimal resistance. If you have a Spherosyn scale, check that the scale is not bent, by removing it and rolling it on a flat surface.

tip

Providing the machine has not been moved more than:

6.3mm (0.25") for a Spherosyn encoder or 2.5mm (0.1") for a Microsyn encoder

the datum position will not be lost by switching the power off and back on again.

tip

When swapping encoders to trace a fault:

1

Check that two axes are set to the correct encoder types.

2

Move the encoder from the malfunctioning axis to a working axis.

If the fault stays with the same encoder, then the encoder is at fault. If the fault does not follow with the encoder the C70 is at fault

If the solutions suggested above do not solve your problem, contact Newall for further instruction.

CLEANING

- Disconnect the power supply from the C70 before cleaning.
- Do not use corrosive or abrasive cleaning materials.
- Do not use compressed air.
- Apply a small amount of mild soap to a lint-free cloth. Use this to wipe over the case and keypad, taking care not to allow fluid into the connectors.



FOLLOW THESE INSTRUCTIONS CAREFULLY TO AVOID DAMAGE TO THE C70.

NEWALL MEASUREMENT SYSTEMS LTD

WORLD HEADQUARTERS
Newall Measurement Systems Ltd.
Technology Gateway, Cornwall Road
South Wigston
Leicester LE18 4XH
ENGLAND
Telephone: +44 (0)116 264 2730
Facsimile: +44 (0)116 264 2731
Email: sales@newall.co.uk
Web: www.newall.co.uk

Newall Electronics, Inc.
1778 Dividend Drive
Columbus, Ohio 43228
Telephone: +1 614.771.0213
Toll Free: 800.229.4376
Facsimile: +1 614.771.0219
Email: sales@newallusa.com
Web: www.newallusa.com

Newall France SARL
63 Rue Victor Hugo
F-59200, Tourcoing
FRANCE
Telephone: +33 (0) 3 20 01 03 13
Facsimile: +33 (0) 3 20 26 13 41
Email: newallfrancesarl@worldonline.fr

Newall Deutschland
Postfach 20
72117 Ammerbuch
GERMANY
Telefon: +49 (0) 7073 302908
Fax: +49 (0) 7073 302963
Email: m.friebe.newall@t-online.de

Newall Korea Ltd.
616-11, Janghang-Dong, Ilsan-Ku
Koyang-Shi, Kyungki-Do
411-380
KOREA
Telephone: +82 (344) 906-8080
Facsimile: +82 (344) 906-8085
Email: newall@hitel.net
Web: www.newall.co.kr